

Assembly Instructions for Pop-up Tent

1. **Choose a Location:** Select a flat, level ground free of sharp objects.
Avoid areas with slopes or uneven surfaces.
2. **Unpack the Tent:** Take out the tent, canopy poles, and other components from the carry bag.
3. **Expand the Tent:** Gently unfold the tent on the ground.
4. **Install the Canopy Poles (Optional):** To create additional shade, use the 4 canopy poles to prop up the side walls. Insert the poles into the designated slots and secure them firmly.
5. **Adjust the Height:** Use the thumb - button system to adjust and fix the tent's height. Make sure all parts are tightly connected.
6. **Finalize Assembly:** Check that the steel tube frame is stable and the tent is properly set up.