
# Model 310-P / 310-PA Multi-Use Stack Chair with Plastic Seat & Back

### **Parts Listing**








D Screws 4 Units Model A310 Arms Optional 2 Units







## **Assembly Instructions**

Tools Needed: Phillips Head Screwdriver Please read all instructions before assembly.


- Step 1: Place Chair Seat (B) onto Chair Base (A). and align screwholes. Insert Screws (D) to secure. Tighten with a screwdriver.
- Step 2: Slide Chair Back (C) onto posts of Chair Base (A). Align holes and insert Screws (D) to secure. Tighten with a screwdriver

#### With Optional Arms (E):

- Step 1: See Step 1 above.
- Step 2: Slide Chair Back (C) onto posts of Chair Base (A).
- Step 3: Slide A310 Arms (E) onto sides of Chair Back (C).
- Step 4: Align holes in arms, back and base and insert Screws (D) to secure. Tighten with a screwdriver.

#### Note:

Once Model A310 Arms are added chair is no longer able to stack.



Ganging Brackets are standard on all Model 310-F/310-P/310-VAM Chairs

#### WEIGHT CAPACITY: 250 lbs.

#### **Assembly Notes:**

During assembly, hand tighten screw only. When all screws are in place, you may then tighten all screws completely.

#### **CAUTION:**

- 1. Do not use this chair as a step ladder.
- 2. Check for loose screws and tighten them every 6 months.



161 Tradition Trail Holly Springs, NC, 27540 800-520-7471 (voice) 919-362-4765 (fax) 919- 303-6389 (voice) www.ofminc.com support@ofminc.com