












Expandable Dish Rack Over Sink


Size 85-100cm




Accessories List Check all the accessories first before installation


① Frame Tube  2/PCS 2/PCS	② Horizontal Tube  2/PCS 4/PCS	③ Bowl Basket  1/PC	④ Plate Basket  1/PC	⑤ Fruit Basket  1/PC
⑥ Detergent Basket  1/PC	⑦ Knife Holder  1/PC	⑧ Chopping Board Rack  1/PC	⑨ Single Chopsticks  1/PC	⑩ Utensil Hooks  5/PC
⑪ Shim  A 4/PCS  B 4/PCS	⑫ Screw  C 4/PCS  D 4/PCS  E 4/PCS	⑬ Wrench  F 1/PC	NOTICE: STYLE WILL BE DECIDED ACCORDING TO YOUR ACTUAL ITEM.	

Assembly Steps

① Frame Tube


② Horizontal Tube


1. Connect with screws

③ Install parts


2. Install frame
a. Tighten with four screws and washer as shown in the picture.

3. Install parts
a. Slide all parts on the frame. It can be customized according to your preference.