

# ESSENTIAL FOLDING BISTRO CHAIR WITH ARMS DMR-752

Understand and follow the care instructions. Save this document for future reference.



## General Care

*Regular and proper care will help preserve the quality of your furniture for many Sunnydaze to come!*

- 1. Clean Often:** Use a damp cloth to clean as needed and wipe dry with a soft cloth. Never use harsh chemicals or abrasive materials to clean this item.
- 2. Protect:** Always wipe up moisture promptly and dry with a soft cloth. Avoid dragging sharp or rough objects across the surface of your wood furniture.
- 3. Exposure:** Over time, sunlight and weather elements may change the color of natural wood. Avoid leaving wooden furniture in the rain or high-humidity climates as wood can expand and contract with humidity changes; you may need to tighten fittings periodically. If this item is not used for extended periods, cover or store it indoors.
- 4. Winter Care & Storage:** Cover and store the furniture during the winter to protect it from ice and snow. Doing so will preserve the appearance and integrity of the item.

**Any modification or failure to follow the recommended care will void the product warranty.**