

easylift

Trim-at-Home Pleated & Cellular Shades by Redi Shade

Use & Care

Use

Use the middle of bottom rail to raise and lower the shade.

Cleaning

- General Cleaning-Lightly dust and/or vacuum with upholstery attachment.
- Spot Cleaning- Lightly blot stain using sponge with soap or mild detergent and warm water. Fully open shade and allow to air dry. Entire shade can be cleaned this way if necessary.

Caution

- Dry cleaning, ultrasonic cleaning, spot remover, strong detergent, and full water immersion are not recommended.



Redi Shade Customer Service: 1-888-608-6611