

Instructions / Assembly

1. Carefully unpack the arcade cabinet and verify all parts are included.
2. Attach the base to the cabinet using the provided hardware.
3. Connect the control deck wiring harness to the main board.
4. Secure the back panel and ensure ventilation openings remain unobstructed.
5. Plug the unit into a grounded outlet and power it on to begin gameplay.

Use and Care Manual

- Place the arcade unit on a flat, stable surface away from moisture.
- Clean the exterior with a soft, dry cloth—do not use chemicals.
- Avoid blocking speakers or ventilation areas.
- Turn off and unplug the game before cleaning or moving it.
- For best performance, keep firmware and internal components free of dust.

Warranty

This product includes a 1-year limited warranty covering defects in materials and workmanship. The warranty does not cover damage due to misuse, modification, or improper assembly. For service, contact customer support with your purchase receipt and product serial number.