




SWJ701E



SWJ701E PARTS LIST

ITEM NUMBER	ITEM DESCRIPTION	PRICE
SWJ701E-1	LABEL	
SWJ701E-2	NUT COVER	
SWJ701E-3	HEX NUT	
SWJ701E-4	AXLE SLEEVE	
SWJ701E-5	END CAP	
SWJ701E-6	SEAL RING	
SWJ701E-7	E TYPE RING	
SWJ701E-8	CHAIN WHEEL	
SWJ701E-9	TENSION SPRING	
SWJ701E-10	WARNING LABEL	
SWJ701E-11	SELF-TAPPING SCREW 4*12	
SWJ701E-12	RIGHT HOUSING	
SWJ701E-13	OIL TANK ASSEMBLY	
SWJ701E-13-1	TRANSPARENT OIL TUBE	
SWJ701E-13-2	OIL TANK DELIVERY CONNECTION	
SWJ701E-13-3	SPONGE	
SWJ701E-13-4	OIL TANK CONNECTOR	
SWJ701E-13-5	OIL TANK JOINT RUBBER SLEEVE	
SWJ701E-13-6	OIL TANK	
SWJ701E-14	OIL TANK CAP ASSY'	
SWJ701E-14-1	VALVE	
SWJ701E-14-2	SEALING RING	
SWJ701E-14-3	OIL TANK CAP	
SWJ701E-14-4	OIL TANK COVER	
SWJ701E-15	TENSIONING SCREW	
SWJ701E-16	FLAT GASKET	
SWJ701E-17	TENSION NUT	
SWJ701E-18	SEALING RING	
SWJ701E-19	FOAM-RUBBER WASHER	
SWJ701E-20	SUNK HEAD SCREW 4*12	
SWJ701E-21	HEAT INSULATION WASHER	
SWJ701E-22	BOLT	
SWJ701E-23	CLAMP	
SWJ701E-24	CLAMP	
SWJ701E-25	OUTPUT SHAFT ASSY'	
SWJ701E-25-1	BEARING	
SWJ701E-25-2	OUTPUT SHAFT	
SWJ701E-25-3	BRAKING SPRING	
SWJ701E-25-4	AXLE SLEEVE	
SWJ701E-25-5	OUTPUT SHAFT GEAR	
SWJ701E-25-6	BEARING	

SWJ701E-25-7	SELF-LOCKING NUT	
SWJ701E-26	BAR COVER	
SWJ701E-27	CHAIN 18'	
SWJ701E-28	CHAIN BAR 18'	
SWJ701E-29	SPANNER	
SWJ701E-30	DUST COVER	
SWJ701E-31	MOTOR ASSY'	
SWJ701E-31-1	FLANGE NUT	
SWJ701E-31-2	MOTOR WHEEL GEAR	
SWJ701E-31-3	BUSH	
SWJ701E-31-4	SELF-TAPPING SCREW 4*16	
SWJ701E-31-5	BEARING PLATE	
SWJ701E-31-6	WIND SCREEN	
SWJ701E-31-7	BEARING	
SWJ701E-31-8	ROTOR 1800W	
SWJ701E-31-9	BEARING	
SWJ701E-31-10	STATOR SCREW	
SWJ701E-31-11	SPRING WASHER	
SWJ701E-31-12	FLAT GASKET	
SWJ701E-31-13	WASHER	
SWJ701E-31-14	HEX NUT	
SWJ701E-31-15	STATOR 1800W	
SWJ701E-31-16	CONNECTING WIRE	
SWJ701E-31-17	CONNECTING WIRE	
SWJ701E-31-18	CONNECTING WIRE	
SWJ701E-31-19	MOTOR HOLDER	
SWJ701E-31-20	BRUSH HOLDER	
SWJ701E-31-21	CARBON BRUSH	
SWJ701E-31-22	BAFFLE	
SWJ701E-31-23	SELF-TAPPING SCREW 3*8	
SWJ701E-32	SELF-TAPPING SCREW 3*12	
SWJ701E-33	TUBE	
SWJ701E-34	OIL PUMP ASSY'	
SWJ701E-34-1	OIL PUMP	
SWJ701E-34-2	PLUNGER COVER	
SWJ701E-34-3	PLUNGER SHELF	
SWJ701E-34-4	WORM WHEEL	
SWJ701E-34-5	WORM WHEEL TOOTH	
SWJ701E-34-6	OIL PUMP TENSION SPRING	
SWJ701E-35	SUNK HEAD SCREW 4*12	
SWJ701E-36	BRAKE LEVER FIXED PLATE	
SWJ701E-37	BRAKE LEVER	
SWJ701E-38	BRAKE LEVER SPRING	
SWJ701E-39	WASHER	
SWJ701E-40	SELF-TAPPING SCREW 4*10	
SWJ701E-41	SPRING LAMINATION	
SWJ701E-42	CONNECTING WIRE	
SWJ701E-43	DELIVERY CONNECTION HOLDER	

SWJ701E-44	SELF-TAPPING SCREW 5*16	
SWJ701E-45	WASHER	
SWJ701E-46	WIND SCREEN	
SWJ701E-47	LEFT HOUSING	
SWJ701E-48	LABEL	
SWJ701E-49	MOTOR COVER	
SWJ701E-50	SCREW	
SWJ701E-51	DELIVERY CONNECTION SEAT	
SWJ701E-52	RUBBER RING	
SWJ701E-53	CABLE	
SWJ701E-54	CABLE CLAMP	
SWJ701E-55	CAPACITANCE	
SWJ701E-56	CABLE SHEATH	
SWJ701E-57	SWITCH	
SWJ701E-58	CONTROL SWITCH	
SWJ701E-59	SWITCH BUTTON	
SWJ701E-60	LOCK OF BUTTON	
SWJ701E-61	LOCK OF SPRING	
SWJ701E-62	FRONT PUSH ROD ASSY'	
SWJ701E-62-1	FRONT PUSH ROD	
SWJ701E-62-2	PIN	
SWJ701E-62-3	CONNECTING ROD	
SWJ701E-63	WASHER	
SWJ701E-64	BRAKE BAR CLAMP	
SWJ701E-65	BACK-MOVING SPRING	
SWJ701E-66	PUSH ROD ASSY'	
SWJ701E-66-1	PUSH ROD	
SWJ701E-66-2	GEAR	
SWJ701E-66-3	PIN	
SWJ701E-67	PUSH ROD CLAMP	

Parts available on snowjoe.com

For parts not available on snowjoe.com
contact us at 1-866-SNOWJOE.