

Item # 716 340
Model # G3600AP-US




USE AND CARE GUIDE

36 IN. PEGBOARD

Questions, problems, missing parts?
Before returning to the store, call
Husky Customer Service
8 a.m. - 5 p.m., EST, Monday - Friday

1-888-HD-HUSKY

WWW.HUSKYTOOLS.COM



Due to continuing improvements,
the actual product may differ slightly
from the product described herein.

THANK YOU

We appreciate the trust and confidence you have placed in Husky through the purchase of this pegboard. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Husky!


Table of Contents

Table of Contents	2	Assembly	3
Safety Information	2	Coordinating Products	4
Warranty	2	Maintenance	4
Specifications	2	Care and Cleaning	4
Pre-Installation	2	Service Parts	4


Safety Information


To reduce the risk of serious injury, read and follow the safety instructions below before assembling and using this product.

- This product is intended for indoor use only.
- This product is not designed for commercial nor industrial usage.


 **CAUTION:** Any assembly or maintenance of the product must be carried out by adults only.

 **CAUTION:** Arrange for necessary manpower when assembling, installing and moving the product.


 **CAUTION:** DO NOT alter this product in any manner. For example, do not weld external bar locks or attach electrical equipment. This may cause product damage or personal injury.

 **WARNING:** Keep the product on level surfaces. The product could become unstable and it may tip over if stored or moved on an uneven surface, which may cause personal injury, death or product damage.

 **WARNING:** This product must be securely mounted on wall before using.

 **WARNING:** DO NOT stand on this product. You may fall which may cause personal injury or death.

 **CAUTION:** Check all nuts and bolts periodically for tightness. When required, tighten them.

 **CAUTION:** DO NOT leave children unattended near this product.

Warranty


This warranty excludes incidental/inconsequential damages and failures due to misuse, abuse or normal wear and tear. This full warranty gives you specific rights, and you may also have other rights, which vary state to state. Contact the customer service team at 1-888-HD-HUSKY or visit www.huskytools.com.

Specifications

Maximum load for pegboard	50 lbs. / 22.7 kg
---------------------------	-------------------

Pre-Installation

TOOLS REQUIRED



Drill
(not included)




Safety Goggles
(not included)



Socket (10 mm)
(not included)



Level
(not included)



Measuring Tape
(not included)

Pre-Installation (continued)

HARDWARE INCLUDED




NOTE: Bolt not shown to actual size.



Part	Description	Quantity
AA	M6 x 40 hex tapping bolt	8

PACKAGE CONTENTS



Part	Description	Quantity
A	Pegboard	2
B	Plastic cover	16



Assembly

HANG THE PEGBOARD

- Install the pegboard (A) to the wall with four M6 x 40 hex tapping bolts (AA) using a power drill.
- Cover the eight holes with plastic covers (B). Make sure the pegboard is securely in place.
- Repeat the same to install the other pegboard (A).





CAUTION: It is recommended to insert the M6 x 40 hex tapping bolts (AA) into the studs of the wall. Loading capacity will be reduced if the pegboard is not secured to studs, and drywall anchors (not included) are suggested to use when the pegboard cannot be installed to studs.




Coordinating Products


This product coordinates well with the units below to offer a best storage solution. They can be combined into various combinations to meet different storage requirements.



Husky 36 in. wall shelf



Husky 36 in. pegboard



Husky 72 in. workbench


Maintenance

- Check all the screws and nuts periodically for tightness. Tighten them when necessary.

Care and Cleaning

- Periodically clean the surfaces with a soft rag and water.
- Grease and oil can be removed with most standard cleaning fluids. For safety, use a nonflammable cleaning fluid.

Service Parts



Part	Replacement Part #	Description	Quantity
B	314147	Plastic cover	16
C	314027	Grommet	2
AA	320328	M6 x 40 hex tapping screws	8



Questions, problems, missing parts? Before returning to the store,
call Husky Customer Service
8 a.m.-5 p.m., EST, Monday-Friday

1-888-HD-HUSKY

WWW.HUSKYTOOLS.COM

Retain this manual for future use.