



# STANDING CAT SCRATCHER



## Included




 **WARNING: CHOKING HAZARD**  
Small parts NOT for children under 3 years




- Assemble your unit on a flat even surface
- Make sure zBoard surfaces are clean and dry


- When moving your Way Basics unit, lift from the bottom
- Indoor use only. Not in bathroom.




- 1** Carefully remove the protective layer on Side zBoard and Bottom zBoard (making sure not to remove the 3M adhesive shown in yellow).




- 2** Apply glue in all holes before inserting alignment pins.




- 3** Apply glue in all holes and insert alignment pins. Secure Side zBoards to the Vertical Scratcher as shown.



- 4** Apply glue in all hole and insert alignment pins. Secure Bottom zBoard to the Back zBoard as shown.



- 5** Apply glue in all holes and insert alignment pins. Secure Front zBoard as shown.



- 6** Flip product vertically and place Base Scratcher as shown. Prop against a wall and scratch away!

