

Item # 1001 624 010
Model # G3600AS-US



USE AND CARE GUIDE

36 IN. WALL SHELF

Questions, problems, missing parts?


Before returning to the store, call

Husky Customer Service

8 a.m. - 5 p.m., EST, Monday - Friday

1-888-HD-HUSKY

WWW.HUSKYTOOLS.COM



Due to continuing improvements,
the actual product may differ slightly
from the product described herein.

THANK YOU

We appreciate the trust and confidence you have placed in Husky through the purchase of this wall shelf. We strive to continually create quality products designed to enhance your home.

Visit us online to see our full line of products available for your home improvement needs.

Thank you for choosing Husky!

Table of Contents

Table of Contents	2	Assembly	3
Safety Information	2	Coordinating Products	5
Warranty	2	Maintenance	5
Specifications	2	Care and Cleaning	5
Pre-Installation	2	Service Parts	5


Safety Information


To reduce the risk of serious injury, read and follow the safety instructions below before assembling and using this product.

- This product is intended for indoor use only.
- This product is not designed for commercial nor industrial usage.


**CAUTION:** Any assembly or maintenance of the product must be carried out by adults only.

**CAUTION:** Arrange for necessary manpower when assembling, installing and moving the product.

**CAUTION:** Check all nuts and bolts periodically for tightness. When required, tighten them.

**WARNING:** Keep the product on level surfaces. The product could become unstable and it may tip over if stored or moved on an uneven surface, which may cause personal injury, death or product damage.

**WARNING:** This product must be securely mounted on wall before using.

**WARNING:** DO NOT stand on this product. You may fall which may cause personal injury or death.

**CAUTION:** DO NOT leave children unattended near this product.

Warranty







This warranty excludes incidental/inconsequential damages and failures due to misuse, abuse or normal wear and tear. This full warranty gives you specific rights, and you may also have other rights, which vary state to state. Contact the customer service team at 1-888-HD-HUSKY or visit www.huskytools.com.

Specifications

Maximum load for shelf (when distributed evenly)	75 lbs. / 34 kg
---	-----------------

Pre-Installation

TOOLS REQUIRED

					
Drill (not included)	Safety Goggles (not included)	Socket (10 mm) (not included)	Level (not included)	Measuring Tape (not included)	Gloves (not included)

Pre-Installation (continued)

HARDWARE INCLUDED




NOTE: Bolt not shown to actual size.



Part	Description	Quantity
AA	M6 x 40 hex tapping bolt	2

PACKAGE CONTENTS



Part	Description	Quantity
A	Back panel	1
B	Left side panel	1
C	Bottom panel	1
D	Right side panel	1
E	Mounting bracket	1

Assembly




NOTE: Assemble on a flat surface. A piece of cardboard is recommended to keep the product from being scratched during assembly.



CAUTION: Please wear gloves during the whole assembling process.

1 ATTACH THE BOTTOM AND BACK PANELS


Attach the bottom panel (C) to the back panel (A) by sliding the back panel's (A) edge into the groove of the bottom panel(C).



Assembly (continued)

2 ATTACH THE SIDE PANELS

Attach the side panels (B & D) to the unit. Slide the bottom panel's (C) side edges into the grooves of the side panels (B & D).



3 HANG THE WALL SHELF


CAUTION: Make sure the wall shelf is securely attached to the mounting bracket.

CAUTION: Use a level to make sure the wall shelf is level after installation.

CAUTION: It is recommended to insert the M6 x 40 hex tapping bolts (AA) into the studs of the wall. Loading capacity will be reduced if the mounting bracket is not secured to studs, and drywall anchors (not included) are suggested to use when the mounting bracket can not be installed to studs.



NOTE: Additional holes in bottom panel may be used for installing a shop light or other accessories. (sold separately)

- Fix the mounting bracket (E) on the wall with two M6 x40 hex tapping bolts (AA) using a power drill.
- Hang the wall shelf onto the mounting bracket (E). Make sure the wall shelf is securely attached to the wall.




Coordinating Products


This product coordinates well with the units below to offer a best storage solution. They can be combined into various combinations to meet different storage requirements.



Husky 36 in. wall shelf



Husky 36 in. pegboard



Husky 72 in. workbench


Maintenance

- Check all the screws and nuts periodically for tightness. Tighten them when necessary.

Care and Cleaning

- Periodically clean the surfaces with a soft rag and water.
- Grease and oil can be removed with most standard cleaning fluids. For safety, use a nonflammable cleaning fluid.

Service Parts



Part	Replacement Part #	Description	Quantity
A	229813	Back panel	1
B	229811	Left side panel	1
C	229814	Bottom panel	1
D	229812	Right side panel	1
E	226387	Mounting bracket	1
AA	320328	M6 x 40 hex tapping bolt	2



Questions, problems, missing parts? Before returning to the store,
call Husky Customer Service
8 a.m.-5 p.m., EST, Monday-Friday

1-888-HD-HUSKY

WWW.HUSKYTOOLS.COM

Retain this manual for future use.