


DIMENSIONS



Freestanding Range

Model Size	A	B	D	E
36"	6.0" (15cm)	6.0" (15cm)	35.6" (90.5cm)	25" (63.5cm)

Warning:

Cabinets 13 in. deep and not less than the nominal width of the appliance must be installed at least 30 in. above the cooking surface.

Cabinets maximum 13 in. deep may be installed on both sides of the appliance with the bottom of the cabinets at least 18 in. above the plane of the cooking surface.