

Vanity Light Installation Instructions

Thank you for purchasing AA Warehousing vanity light. Please follow these instructions carefully to ensure a safe and proper installation. If you are not familiar with electrical wiring, we recommend consulting a licensed electrician.

Tools Needed:

- Screwdriver (Phillips and flathead)
- Wire strippers
- Voltage tester
- Drill (if needed)
- Mounting screws (included)
- Wall anchors (if needed)
- Safety glasses



Safety Instructions:

1. Turn off the electricity at the main circuit breaker before starting installation.
2. Ensure the power is off by using a voltage tester.
3. Always use proper tools and wear safety equipment.
4. If in doubt, consult a professional electrician.

Installation Steps:

Step 1: Turn off the Power

Turn off the power to the lighting circuit by switching off the breaker at your electrical panel. Use a voltage tester to confirm that the power is off.

Step 2: Prepare the Mounting Bracket

Remove the mounting bracket from the back of the vanity light fixture. Position the bracket over the junction box and secure it with the screws provided. If the bracket doesn't align with the holes in the box, drill new holes as needed and use wall anchors.

Step 3: Connect the Wires

Carefully connect the wires: black (hot) to black, white (neutral) to white, and green or bare copper (ground) to the grounding screw or wire in the junction box. Secure the connections with wire nuts and ensure no exposed wire remains.

Step 4: Attach the Fixture

Once the wires are connected, gently tuck them into the junction box. Align the vanity light fixture with the mounting bracket and secure it with the provided screws. Make sure the fixture is level.

Step 5: Install Light Bulbs

Install the correct type of light bulbs as recommended in the fixture manual. Avoid using bulbs with a higher wattage than the fixture is rated for.

Step 6: Restore Power

Once installation is complete, turn the power back on at the breaker. Test the light fixture to ensure it is working properly.

Enjoy your new vanity light! For any issues or additional support, please contact our customer service team.

Warranty:

One year limited manufacturer warranty applies to products purchased from AA Warehousing. Warranty covers any defects in material or workmanship under normal use during the warranty period. AA Warehousing may repair or replace products or parts of the product that prove defective. Warranty does not cover any problem caused by improper maintenance, damage resulting from natural disasters, theft or loss of the product.