



TODDLER SWING SEAT

MODEL# 9303SS

PRODUCT MANUAL - VERSION 1.21.01

FOR AGES:

3-7

WEIGHT LIMIT:

100 Lbs

TO BUILD:



HOW-TO
VIDEOS ONLINE



Manual en
español ubicado
en GQBrands.com

Spanish Manual located
at GQBrands.com

CUSTOMER SERVICE

GQBrands.com • CustomerService@GQBrands.com • 1-866-498-5269 • 4401 Samuell Blvd, Ste 150, Mesquite, TX 75149



CUSTOMER SERVICE INFORMATION

Thank you for purchasing: **TODDLER SWING SEAT**

MODEL# 9303SS

If you have an issue with your item, do not return. Please report items that are damaged or missing parts to the manufacturer GQ Brands within three days of delivery. Contact customer service at customerservice@gqbrands.com to open a ticket.

At GQBrands®, we want all of our customers to be completely satisfied with their purchase. Take time to review the contents of the product you have just received to make sure that all of the parts are included. If you find that any parts are missing or damaged, we will provide replacement parts at no charge within 30 days of purchase. Please keep in mind that for select damaged part replacement requests, we will require a photo for submission.

To register your product please visit:
www.globalqualitybrands.com/product-registration
or scan code:



To order these parts, or if you have any other questions or concerns about this GQBrands product, please contact us at

PureFun.Net
GQBrands®
Phone: 1-866-498-5269
Email: CustomerService@GQBrands.com
4401 Samuell Blvd, Ste 150, Mesquite, TX 75149

Please be sure to include the following information when you contact Customer Service:

YOUR NAME: _____

RETAILER WHERE PURCHASED: _____

YOUR MAILING ADDRESS: _____

DATE OF PURCHASE: _____

YOUR EMAIL ADDRESS: _____

ORDER NUMBER: (If Available) _____

PRODUCT NAME: _____

QUANTITY NEEDED: _____

PRODUCT MODEL#: _____

SERIAL NUMBER: _____

PART NUMBER _____

LIMITED WARRANTY

Global Quality Brands® warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of **90 DAYS FROM THE DATE OF ORIGINAL PURCHASE**. This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the company.

All warranty coverage extends only to the original retail purchaser from the date of purchase. GQBrands obligation under this warranty is limited to replacing or repairing, at Global Quality Brands® option. All products for which a warranty claim is made must be received by Global Quality Brands® and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Global Quality Brands®. All warranty claims must be pre-authorized by Global Quality Brands® pre-authorization can be obtained by calling 866-498-5269.

This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of nature, (such as damage caused by wind, lightning, snow, water, or ice) weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other warranty beyond that specifically set forth above is authorized by GQBrands®.

GLOBAL QUALITY BRANDS® IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY,

THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND GLOBAL QUALITY BRANDS®, SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

WHILE EVERY ATTEMPT IS MADE TO ENSURE THE HIGHEST DEGREE OF PROTECTION IN ALL EQUIPMENT, WE CANNOT GUARANTEE FREEDOM OF INJURY. THE USER ASSUMES ALL RISK OF INJURY DUE TO USE. ALL MERCHANDISE IS SOLD ON THIS CONDITION, WHICH NO REPRESENTATIVE OF GQBRANDS® CAN WAIVE OR CHANGE.

WARNINGS

CHOKING HAZARD

Small Parts **NOT** for children under 3 years of age. Adult assembly required.

PROP 65 WARNING

THIS PRODUCT CAN POSSIBLY EXPOSE YOU TO CHEMICALS INCLUDING DI(2-ETHYLHEXYL) PHTHALATE (DEHP), WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER AND BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM. FOR MORE INFORMATION GO TO WWW.P65WARNINGS.CA.GOV.

Please read these warnings and the information in this manual in its entirety.

Failure to comply with the following instructions may increase the risk of serious injury and/or death:

- This unit must be assembled and disassembled by **ADULTS ONLY**.
- Children must be supervised at all times when using this equipment. **DO NOT** leave children unattended at any time.
- This swing seat is suitable for use by most children between 3 to 7 years of age.
- **DO NOT** exceed the **MAXIMUM WEIGHT** limit of 100Lbs regardless of age.
- **DO NOT** install this swing over concrete or asphalt, or any other hard or rough surface. The swing should always be installed over an appropriate surface (rubber mat, grass, mulch, etc).
- This swing seat is only designed for normal residential use. It is **NOT** intended for commercial applications and/or in public areas such as schools, parks, nurseries, day schools, day cares, etc.
- **ALWAYS** install this swing at least 7 feet away from any structure, obstruction, or possible hazard(s) such as walls, pools, power lines, overhangs, other playground equipment, driveways, hard surfaces and/or roadways.
- **DO NOT** allow more than one person on the swing at a time.
- **DO NOT** attach items to the swing not specifically designed for this purpose.
- Always be sure that the swing is clear of any persons, pets or obstructions before swinging.
- **DO NOT** allow children to climb on product when product is wet.
- **DO NOT** place objects on or under the swing, or allow people or pets to stand or sit on, near or under the swing when in use.
- **DO NOT** use in adverse weather conditions, while the swing is wet or in poorly lit conditions.
- Always secure the swing against unauthorized or unsupervised use.
- Only one rider should be allowed on the swing at one time.
- Remove any obstructions around the product and play area is clear of any objects.
- Do not twist ropes or loop them over the top support bar since this may reduce their strength.
- Carefully inspect your existing structure you are attaching this Swing Seat to. Look for rusted, damaged or loose bolts, hooks and/or hardware. Replace these before installation.
- We cannot guarantee freedom from injury. The user assumes all risks of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

ASSEMBLY INSTRUCTIONS

Installation Instructions:

1. Remove the product from its packaging and inspect the rope, connection rings and the seat to ensure there is no fraying to the rope or damage to the seat and/or the connection rings.
2. Carefully inspect your existing attachment hooks and/or hardware on your swing set.

*Replace any damaged, rusted, or broken parts before installation.

*It is strongly recommended that the rings on the Swing Seat rope should be attached to swing set hardware that has a nylon bushing where the existing hook will pivot. If this hardware is not present on your set, you should add hooks with this bushing (sold separately.)

3. Once attached, adjust the height of the Swing Seat using the height adjustment buckles located near the top of each rope end. You must ensure that the Seat is level. This Swing Seat should never be hung so that it is less than 8" from the ground or more than 2 feet (24") above the ground.
4. Before use, test your connections by using steady, sufficient downward force on the Swing Seat. It is recommended that you test the Swing Seat connections at multiple swing positions to insure against possible slippage of the connectors due to faulty hardware or installation.
5. Once you are certain that the product is installed properly. You may begin using it. Use caution and judgment when supervising your child's use of this product. Always pay attention to the speed and angle of your child's swing to prevent accidents. NEVER exceed 100 LBS.

ADULT INSTALLATION REQUIRED:

This Swing Seat is intended for use only as a replacement seat for a swing set and/or installation on an existing structure intended for use as such.

Attachment hooks and hardware may be required (sold separately).



FREQUENTLY ASKED QUESTIONS

Question: "A part is damaged, how do I replace it?"

Answer: If you are still within your warranty period (90 days from initial purchase) You should contact customer service. You can also purchase select replacement parts at: www.purefun.net

Question: "I had a part missing from my box" or "something was damaged during assembly, can you send it to me?"

Answer: If it has been 30 days or less from the date of your initial purchase, you can contact customer service for a replacement part to be issued.

Question: "Where can I get the hardware to attach this swing to a swingset?"

Answer: The hardware can be found at a local hardware store. You will need swing set hardware that has a nylon bushing where the existing hook will pivot.

Thank You Coupon!

As a way of saying thank you for purchasing one of our products, here is a 10% OFF coupon for your next purchase at

www.PureFun.net

Use Code: GQBRANDS10 at Checkout