TRAMONTINA

GOURMET

ROASTING PANS

Use & Care Instructions Using Your 18/10 Stainless Steel Roasting Pan

- Before using your roasting pan for the first time, hand-wash with warm, soapy water. Rinse and dry thoroughly.
- Keep the roasting pan in the oven only during the necessary time for cooking or baking. Do not overheat empty pan. Pan and basting grill are oven-safe up to 500°F / 260°C.
- To prevent warping, avoid sudden temperature changes such as immersing hot pan in cold water. Always let the roasting pan cool before washing.
- Do not leave or store food remains in the roasting pan for long periods of time. Superficial pitting may occur if very salty or acidic foods are left in the pan.

Cleaning and Caring For Your 18/10 Stainless Steel Roasting Pan

- Stainless steel roasting pan and basting grill are dishwasher-safe. However, we recommend hand-drying the roasting pan and basting grill immediately after the rinse cycle or hand-washing and drying to preserve the original finish.
- Prolonged exposure to high heat settings may cause your roasting pan to discolor. To recondition
 your roasting pan or to remove stubborn spots or stains, use a nonabrasive pad and quality stainless
 steel cleanser such as Bar Keepers Friend[®].

IMPORTANT

- TO AVOID INJURY, ALWAYS USE PROTECTIVE MITTS TO SAFELY HANDLE HOT ROASTING PAN.
- OVEN-SAFE UP TO 500°F (260°C)

Stainless Steel Basting Grill

- After use, remove the grill from the roasting pan and wash with warm, soapy water then rinse and dry thoroughly.
- For hard-to-clean, stuck-on foods, soak for an extended period and then wash by hand or in the dishwasher.



 Available Sizes:

 16.75 x 13.75 x 2.5 in
 42.5 x 34.9 x 6.3 cm

 18.75 x 14.75 x 3 in
 47.6 x 37.4 x 7.6 cm

 (Outside Dimensions)

Oven-Safe Dishwasher-Safe

Lifetime Warranty

This product is warranted by TRAMONTINA to be free from defects in material and workmanship for the lifetime of the original purchaser. Any piece will be repaired or replaced at no charge with the same item or one of equal or better value if it is found to be defective under normal, noncommercial household use and when cared for according to the manufacturer's instructions. This warranty does not cover lost or stolen items or defects caused by accidents, fire, or abuse or misuse of the products, including but not limited to overheating, improper cleaning with harsh cleansers or detergents, neglect, alteration, or use in commercial establishments.

For repair or replacement, return defective merchandise by package delivery service or insured parcel post with a letter of explanation to the customer service department listed below.

This warranty gives you specific legal rights, and you may also have other rights, which vary according to country, state or province.

Any questions regarding this warranty and/or the use and care of this product should be directed to:

TRAMONTINA

TRAMONTINA USA, Inc. Customer Service 12955 West Airport Blvd. Sugar Land, TX 77478-6119 (800) 221-7809 www.tramontina-usa.com

MADE IN BRAZIL

ASSEMBLED AND PACKAGED IN USA

80203/009DS 80203/010DS