

## **Proper Use & Care**

- Inspect upon receipt and before each use.
  Never climb a damaged, bent or broken stool.
- Place on a firm level, non-slippery surface.
- When using stool, keep two feet centered on stool and do not over-reach.
- Check stool for missing or damaged parts.
- Store stool in a safe and dry place.
- Keep stool clean and free of all foreign materials.