
## **SPECIFICATIONS**

## **LOCATION OF MODEL NUMBER**

To request service information or replacement parts, the service center will require the complete model number of your microwave oven. The number is on the inside of the door frame as shown in the illustration helow



### **OVEN SPECIFICATIONS**

Output Power 1.000W (IEC 60705 Standard) Outer Dimensions 29 7/8" x 16 7/16" X 15 13/16"

Cavity Volume 2.0 Cu.ft Net Weight 68.3 lbs

#### **ELECTRICAL RATING**

- \* Electrical Rating of the Oven:120V AC 60Hz
- \* 14 Amps / 1600 Watts ( MWO + Cooktop Lamp
- + Ventilation Fan)

# **ELECTRICAL** REQUIREMENTS

The oven is designed to operate on a Standard 120V/60Hz household outlet. Be sure the circuit is at least 15A or 20A and the microwave oven is the only appliance on the circuit. It is not designed for 50Hz or any circuit other than a 120V/60Hz circuit.

## **GROUNDING** INSTRUCTIONS

This appliance must be grounded. If an electrical short circuit occurs, grounding reduces the risk of electric shock by providing an escape wire for the electric current. The cord for this appliance has a grounding wire with a grounding plug. Put the plug into an outlet that is properly installed and grounded.


## WARNING - If you use the

grounding plug improperly, you risk electric shock.

Ask a qualified electrician if you do not understand the grounding instructions or if you do not know whether the appliance is properly grounded.

Because this appliance fits under the cabinet, it has a short power-supply cord. See the separate Installation Instructions for directions on properly placing the cord. Keep the electrical power cord dry and do not pinch or crush it in any way.

If it is necessary to use an extension cord, use only a 3-wire extension cord that has a 3-blade grounding plug, and a 3-slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord should be equal to or greater than the electrical rating of the appliance.



For a permanently connected appliance: This appliance must be connected to a grounded, metallic, permanent wiring system, or an equipment grounding conductor should be run with the circuit conductors and connected to the equipment grounding terminal or lead on the appliance.