


Item # 100 643 3447  
Model #FRN-312640-L

# HAMPTON BAY®

## USE AND CARE GUIDE

---

### HEATHER GLEN LOUNGE CHAIR



Questions, problems, missing parts? Before returning to the store,  
call Hampton Bay Customer Service  
8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

**1-800-841-1350**

**HAMPTONBAY.COM**

---

#### **THANK YOU**

*We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this lounge chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!*

## Table of Contents

Safety Information .....	2
Warranty .....	2
Care and Cleaning .....	2
Assembly .....	3-7
Hardware Included .....	3
Package Contents .....	4
Assembly .....	5-7

## Important Safety Instructions

### READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

SAVE THESE INSTRUCTIONS.



**DANGER:** Keep children out of the assembly area during assembly.



**CAUTION:** Do not use sharp equipment such as a knife and scissors when removing the protective material, as it may damage the product.



**WARNING:** Do not stand on the chair.

## Warranty

### TWO YEAR LIMITED WARRANTY

#### WHAT IS COVERED

The frame is warranted to be free of manufacturing defects for two year from the purchase date. If the frame of your furniture fails (ie. broken frame or weld) within two year of ownership, Hampton Bay will repair, provide replacement parts, or replace the product at our option. Frame finishes are warranted against blistering, cracking, or peeling for two year from purchase date. This is a residential use warranty only. Warranty is void when product is used for commercial settings. This warranty is a limited warranty and applies to the original purchase only. Proof of purchase is required.

Contact the Customer Service Team at 1-800-841-1350 or visit [hamptonbay.com](http://hamptonbay.com)

## Care and Cleaning

- ☐ Use mild soap and warm water to clean the frames.
- ☐ Rinse with clean water and dry thoroughly.
- ☐ Be sure to drain any water accumulated inside the frames. To thoroughly drain frames, remove footcaps and tilt frames, if necessary, to remove all water. Water allowed to accumulate inside the frames and then exposed to sub-freezing temperatures can cause damage to frame tubing. Such damage caused by conditions other than normal is not covered under warranty.
- ☐ Any rust spots should be lightly sanded and treated with rust inhibitor and followed with an application of touch-up paint (not included).

# Assembly

## PLANNING ASSEMBLY


Before beginning the assembly of this product, make sure all parts are present. Compare parts with Package Contents and Hardware Included lists. If any part is missing or damaged, do not attempt to assemble the product, and return it to the place of purchase. Assembly requires two people.

## HARDWARE INCLUDED



**NOTE:** Hardware not shown to actual size.

**AA**



**BB**



**CC**



**DD**



**EE**



**FF**



**GG**



Part	Description	Quantity
AA	Bolt M8*35mm	4
BB	Bolt M6*15mm	8
CC	Bolt M6*35mm	6
DD	Small Washer	14
EE	Larger Washer	4
FF	Plastic Washer	2
GG	Hex Wrench	1

## Assembly (continued)




**NOTE:** Content not shown to actual size.

### PACKAGE CONTENTS


**A**




**B**




**C**



**D**



**E**



**F**



**G**



**H**




Part	Description	Quantity
A	Front Leg	2
B	Chaise Seat	1
C	Center Leg	1
D	Back Leg	1
E	Armrest	2
F	Chaise Back	1
G	Seat Cushion	1
H	Back Cushion	1

## Assembly (continued)


### 1 Attaching the Front Legs to the Chaise Seat

- Place all parts on a flat, clean surface.
- Attach the Front Legs (A) to the Chaise Seat (B), by using Bolts (AA), Larger Washers (EE) and Hex Wrench (GG).
- Do not overtighten the bolts.



### 2 Inserting the Armrest to the Legs


- Insert the Armrests (E) to the Center Leg (C) and Back Leg (D), by using the Bolts (BB), Washers (DD) and Hex Wrench (GG).
- Do not overtighten the bolts.



## Assembly (continued)


### 3 Attaching the Assembled Seat to the Legs

- Attach the Assembled Seat to the Center Legs (C) and Back Legs (D), by using the Bolts (CC), Small Washers (DD).
- Tighten all the bolts with Hex Wrench (GG).



### 4 Connecting the Chaise Back to the Seat



- Connect the Chaise Back (F) to the assembled Seat (as shown), using the Bolts (CC), Small Washers (DD) and Plastic Washers (FF).



## Assembly (continued)

### 5 Put the Cushions on the Chaise

- Put the Seat Cushion (G) and Back Cushion (H) on the Chaise.
- Now the Chaise is ready for use.



# HAMPTON BAY®

For certification use only
Factory chaise lounge ID # FRN-312640-L

Questions, problems, missing parts? Before returning to the store,  
call Hampton Bay Customer Service  
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

**1-800-841-1350**

**HAMPTONBAY.COM**

Retain this manual for future use.