



8' Picnic Table

Model# 11116

Assembly Instructions

Part #	Description	Box#	Qty
1	1½ x 5½ x 96" Table Rail (with wood)	1	3
2	1½ x 5½ x 96" Table Rail	1	2
3	1½ x 5½ x 96" Seat Rail (with wood)	2	4
4	1½ x 5½ x 59½" Cross Brace	1	2
5	1½ x 5½ x 30¾" Leg (with wood)	2	4
6	25½" Table Bracket	2	2
7	8¾" Seat Bracket	2	4
8	⅞ x 1½ x 27" Center Brace	2	1
9	⅞ x 1½ x 33¾" Diagonal Brace	2	2
10	28" Table End Cap	2	2
11	11 ⅞" Seat End Cap	2	4
12	6 ⅞" Leg End Cap	2	4
13	5½" Cross Brace End Cap	2	4
14	Hardware Bag (includes:)	2	1
	⅞ x 1½" End Cap		2
	¾" Painted Screw		72
	2" Painted Screw		12
	¼ x 3½" Bolt		8
	¼ x 2¼" Bolt		18
	¼" Nylock Nut		26
	¼" Flat Washer		52
	Super Glue Tube		2

General Information

PLEASE READ THROUGH BEFORE BEGINNING ASSEMBLY.

IMPORTANT: Check boxes for Contents Listed

Check inside of parts as some parts are packaged inside of others

In the event of missing, damaged or defective parts please call our customer service dept. at 1-877-258-6020

When assembling components, place on a clean, flat non-abrasive surface to avoid scratches

Tools Required

- ... Battery or Electric Drill with #2 phillips bit, ¼", ⅝" drill bits
- ... Two 7/16" wrenches or sockets
- ... Tape Measure
- ... File