
Assembly Instructions for Outdoor Kitchen Table

Tools Required: No tools needed, easy manual operation

Unpack the Table

Remove the table from the carrying bag and place it on a flat, stable surface.

Open the Table

1.Unfold the Tabletop: Gently pull the sides of the folded table apart until the tabletop is fully extended and flat.

2.Extend the Frame: Locate the frame system underneath the table. Slowly unfold the frame and ensure that it is fully extended and securely locked into place.

Secure the Frame

Lock the Frame: If your table has a locking mechanism, make sure it is engaged to ensure the frame remains stable.

Adjust Stability: If the table has adjustable legs, set each leg to ensure the table is level and stable on the ground.

Install Additional Components (if applicable)

Attach Shelves or Storage Bags: If the table includes additional shelves or storage bags, attach them to their designated positions according to the provided instructions.

Ensure Secure Installation: Verify that all additional components are firmly attached and positioned correctly.

Final Check

Verify Stability: Check that the table is stable and does not wobble. Adjust as necessary.

Clean the Table: Remove any packaging materials or debris from the tabletop to prepare it for use.

Usage Guidelines

Check Weight Capacity: Be aware of the table's maximum weight capacity and avoid exceeding it.

Regular Maintenance: Clean the table regularly to keep it in good condition.

Important Notes:

- Read the product manual thoroughly before assembly to ensure proper setup and usage.
- For any issues or damage, contact the manufacturer or supplier for assistance.