


81096 ENGINE

NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.
1	1E36FE.9-3	Screw	1	26	HA46.2.1.1	MAGNETO ROTOR COMP.	1
2	1E36FE.9-4	Ratchet	1	27	GB/T859	Washer 8	1
3	1E36FE.9-1	Starter Rope Reel	1	28	GB/T97.1	Washer 8	1
4	1E36FE.9-5	Starter Rope	1	29	GB6170	Nut M8	1
5	1E36FE.9-7	Recoil Spring	1	30	1E40F-E.3.1-2	IGNITION COIL COMP.	1
6	1E36FE.9-8	Starter Cover Ass'y	1	31	1E36F-2.3.1	Cord Comp.	1
7	GB9074.4	Screw M5 x 20	5	32	GB9074.13	Bolt M5 x 20	2
8	1E40FP-3Z.4-2	Start Handle	1	33	1E36F-3	WasherB	2
9	1E40FP-3Z.4-10	Ring	1	34	1E36F-E.6A-1	Spring	2
10	1E36FE.9-6	Spring	1	35	1E36F-2C.4.1	Expander	2
11	1E36FE.9-2	Start pole	2	36	1E40F-5-11	Washer	2
12	1E36FE.9	Starter	1	37	1E40F-5-12	Screw Pin	2
13	1E40F-5-10	Gasket	1	38	1E40F-5-9	Fan Cover	1
14	1E36FE.7	Start Reel	1	39	1E40F-5.9	Oil-seal	1
15	1E36F.2	Oil-seal	1	40	GB9074.13	Screw M5 x 25	4
16	1E40F-E.6-2	Crank Case	1	41	1E44F-2A.2-3	Bearing	1
17	1E40F-5.8-4	Gasket	1	42	P40.6-4	Ring	2
18	GB/T276	Bearing 6202/P6	2	43	1E44F-E.3-1	Piston	1
19	1E40F-E.4.1A	Crank Shaft	1	44	1E44F-2A.2-2	Piston Pin	1
20	GB1099	Key 3x5x13	1	45	1E44F-2A.2-4	Piston Ring	2
21	GB119	Pin B5 x 12	2	46	1E40F-5-6	Gasket	1
22	1E40F-E.6-1	Crank Case	1	47	1E44F-E-1	Cylinder	1
23	GB9074.4	Screw M4 x 8	1	48	GB/T70.1	Screw M5 x 20	4
24	GB119	Pin B4 x 10	2	49	1E44FL-E.1A	Guide Cover Ass'y	14
25	GB9074.4	Screw M5 x 30	4	50	L8RTC	Spark Plug	1



NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.
51	1E40F-3A.8-2	Spring	1	76	1E36F-E-5	Stand	1
52	1E34F.5-3	Plug Cap	1	77	1E40F-5A-2	Rubber Cover	1
53	1E34F.5-2	Cap	1	78	P40.12.2-3A	Cleaner Cover	1
54	1E40F-5.3-1	Plug	1	79	CG420.1.3.2-2	Fuel Pipe 3x1.5x145	1
55	1E40F-E-4	Cover	1	80	EB-415.4.2-2	Plug	1
56	1E40F-E-2	Gasket	1	81	EB-415.4.2-4	Fuel Pipe 2.5x1.25x80	1
57	1E40F-2E-DZ.2A	Muffler	1	82	GB/T9074.4	Screw M5 x 16	2
58	GB9074.4	Screw M5 x 12	2	83	1E40F-HS.5.1	Fuel Tank	1
59	GB/T93	Washer 5	2	84	1E32FL.6.2-4	Chain	1
60	GB/T97.1	Washer 5	2	85	1E32FL.6.2-3	End Cover	1
61	GB/T70.1	Screw M5 x 25	2	86	1E32FL.6.2-2	Inside Cover	1
62	1E40F-5-2	Gasket	2	87	EB-415.4.1.1-1	Inlet	1
63	HA46.9	Admitting Pipe	1	88	CG420.1.3.1-2	Gasket	1
64	1E40F-5A-1	Gasket	1	89	1E32FL.6.2-1	Fuel Tank Lid	1
65	1E40F-2E.1A	Carburetor	1	90	1E32FL.6.2	Lid Ass'y	1
66	1E34F.1-2	Choker Handle	1	91	1E40F-5A-3	Rubber washer	2
67	1E34F.1-7	Stop ring	1				
68	GB/T6170	Nut M4	1	93	1E36F-2-10	Label	1
69	1E34F.1.1	Cleaner inside cover	1	94	1E40F-2E-DZ-1	Cover	1
70	GB/T9074.4	Screw M5x50	2				
71	1E34F.1-3	Choker	1	96	GB/T70.1	Screw M6 x 60	2
72	GB/T845	Screw ST4.2X12	1	97	GB/T93	Washer 6	2
73	1E34F.1-1	Filter Net	1	98	GB/T97.1	Washer 6	2
74	1E36F-E.7-1	Cleaner Outside Cover	1	99	1E36F-2C-1	Gasket	1