USE AND CARE GUIDE

COASTER FINE FURNITURE | coasterfurniture.com

Product	Tracy 55 in. W White 2-Drawer Computer Desk
Model / SKU	800108 (Home Depot Internet # 327398330)
Finish	White
Dimensions	55 in. W x 23.5 in. D x 29.5 in. H
Materials	Melamine paper veneer, engineered wood (MDF, PB, honeycomb core) and metal

Customer Service

Warranty claims, missing, damaged or defective parts, or assembly help	Contact Coaster: email **ecomm06@coasteramer.com** or call **(888) 710-5274**. Where the assembly instructions say to contact the store, contact Coaster instead. Have your model number (800108) and proof of purchase ready.
Returns and refunds	Contact The Home Depot, where you purchased this item.

Assembly and Safety

- Assembly instructions follow on the next pages. Check that all parts and hardware are present before you start.

Care and Cleaning

- Dust often with a soft, dry, lint-free cloth, following the grain.
- Wipe up spills right away with a soft cloth lightly dampened with water, then dry the surface.
- Do not use abrasive cleaners, ammonia, solvents or silicone polishes.
- Use felt pads under lamps and decor, and coasters or mats under hot, cold or wet items.
- Wipe metal parts with a soft cloth dampened with mild soap and water, then dry them right away. Do not use abrasive pads or cleaners, which can scratch the finish.
- Keep out of direct sunlight and away from heaters, fireplaces and air vents. Sudden changes in heat or humidity can affect wood and finishes.
- To move it, lift it; do not drag it.

Limited Warranty

- Coaster warrants this product to be free from manufacturing defects in workmanship and materials for one (1) year from the date of purchase.
- Covers residential use only. Industrial, commercial, institutional and rental use are not covered.
- Does not cover color variations, size discrepancies, normal wear or buyer’s remorse.
- Void if damage results from improper use or maintenance, unauthorized modifications, assembly not done according to the instructions, moving the item after delivery, accidents or abuse.
- To make a warranty claim, email Coaster at ecomm06@coasteramer.com or call (888) 710-5274 with your model number and proof of purchase.
- This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800108
COMPUTER DESK

REVISION 0 : 06/06/2018
REVISION 1 : 08/31/2018
REVISION 2 : 06/17/2019
REVISION 3 : 06/27/2022
REVISION 4 : 08/29/2023
REVISION 5 : 09/08/2025

ITEM:**800108**

COASTER FINE FURNITURE

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



















WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME | 70 MINUTES

PARTS IDENTIFICATION




A	LEFT SIDE PANEL		1 PC
B	LEFT DIVIDER PANEL		1 PC
C	RIGHT DIVIDER PANEL		1 PC
D	RIGHT SIDE PANEL		1 PC
E	LEFT BOTTOM PANEL		1 PC
F	RIGHT BOTTOM PANEL		1 PC
G	SMALL LEFT TOP PANEL		1 PC
H	SMALL RIGHT TOP PANEL		1 PC
I	SMALL BACK PANEL		2PCS
J	LARGE BACK PANEL		1 PC
K	KEYBOARD SHELF		1 PC
L	ADJUSTABLE SHELF		1 PC
M	DOOR		1 PC
N	LARGE TOP PANEL		1 PC
O	LARGE DRAWER FRONT PANEL		1 PC
P	LARGE DRAWER BACK PANEL		1 PC
Q	LARGE DRAWER LEFT SIDE PANEL		1 PC
R	LARGE DRAWER RIGHT SIDE PANEL		1 PC
S	SMALL DRAWER FRONT PANEL		1 PC
T	SMALL DRAWER BACK PANEL		1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.





ITEM:800108






COASTER FINE FURNITURE

U	SMALL DRAWER LEFT SIDE PANEL		1 PC
V	SMALL DRAWER RIGHT SIDE PANEL		1 PC
W	DRAWER BOTTOM PANEL		2 PCS

Z

HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC
2	WOODEN DOWEL Ø 8x30mm		38 PCS
3	CAM BOLT (Ø 7x35.5mm SR)		20 PCS
4	CAM LOCK (Ø15x12mm SR)		20 PCS
5	BOLT (Ø 9.5x55mm) FOR BOTTOM PANEL		12 PCS
6	SCREW FOR DRAWER (Ø4.3x35mm SR)		8 PCS
7	DOOR CATCH		1 PC
8	PIN (Ø 4.9x8mm SR)		4 PCS
9	RAIL (L = 350mm SR)		1 SET
10	SCREW FOR RAIL (Ø 3.5x12mm SR)		10 PCS
11	EURO SLIDE (L = 450mm WHT)		2 SET

NO	DESCRIPTION	FIGURE	Q'TY
12	SCREW FOR EURO SLIDE (Ø 3x12mm SR)		28 PCS
13	HANDLE L=120mm		3 PCS
14	HANDLE BOLT (Ø 4x28mm SR)		6 PCS
15	FOOT 50x50x18mm		8 PCS
16	LONG SCREW (Ø 5x23mm BLK)		16 PCS
17	HINGE (Ø 26 SR)		2 PCS
18	SCREW FOR HINGE (Ø 4x15mm SR)		8 PCS
19	IRON BAR L=80mm		4 PCS
20	BOLT FOR IRON BAR (M6x42mm SR)		4 PCS
21	IRON BAR Ø 9.5x311mm SR		2 PCS
22	STICKER Ø 20mm		4 PCS


Z9,Z10,Z11,Z13,Z14,Z15,Z17,Z19,Z21 not included in blister packaging.


NOTE:
Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:**800108**


COASTER FINE FURNITURE


STEP 1






the reverse side






Apply glue on all wooden dowels to ensure integrity of the structure.





ITEM:**800108**


STEP 2

COASTER FINE FURNITURE











Apply glue on all wooden dowels to ensure integrity of the structure.




ITEM:**800108**


COASTER FINE FURNITURE

STEP 3





Apply glue on all wooden dowels to ensure integrity of the structure.





STEP 4







Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**800108**

COASTER FINE FURNITURE


STEP 5






Apply glue on all wooden dowels to ensure integrity of the structure.


STEP 6







ITEM:**800108**


STEP 7






the reverse side







Apply glue on all wooden dowels to ensure integrity of the structure.





ITEM:**800108**


STEP 8













Apply glue on all wooden dowels to ensure integrity of the structure.





COASTER FINE FURNITURE

STEP 9




Apply glue on all wooden dowels to ensure integrity of the structure.






STEP 10





Apply glue on all wooden dowels to ensure integrity of the structure.



ITEM:**800108**


STEP 11






Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 12








ITEM:**800108**


COASTER FINE FURNITURE

STEP 13












Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 14









ITEM:**800108**

STEP 15







Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**800108**


COASTER FINE FURNITURE

STEP 16-1







STEP 16-2



Apply glue on all wooden dowels to ensure integrity of the structure.


STEP 16-3






ITEM:**800108**


STEP 16-4






STEP 16-5










ITEM:**800108**


STEP 17-1






STEP 17-2







ITEM:**800108**


STEP 17-3






STEP 17-4










ITEM:**800108**

STEP 17-5






Insert rails in outside holes for large files.
Insert rails in inside holes for small files.




ITEM:**800108**


COASTER FINE FURNITURE


STEP 18





STEP 19







ITEM:**800108**

COASTER FINE FURNITURE


STEP 20







STEP 21

COMPLETE












ITEM:800108







Note : Dimension tolerance ±5%