




PARTS LIST

- | | |
|--------------------------|--------------------------------|
| 1. Left Label Cover | 10. Center Shaft |
| 2. Inlet Hose Connector | 11. Drum Wheel Inner Cap |
| 3. Left Case | 12. Spring |
| 4. Belt | 13. Spring Housing Outer Cover |
| 5. Guide | 14. Tension Cover |
| 6. Air Hose | 15. Right Label Cover |
| 7. Drum Wheel | 16. Plastic Pivot |
| 8. Ratchet Plate | 17. Mounting Bracket |
| 9. Ratchet Lock Assembly | |