






OPERATING  
INSTRUCTIONS  
&  
PARTS MANUAL  
(OIPM)

Folding Gate - **Single Door**


Check product SKU codes and sizes

SKU	Product Stretching Size
SSFDMDM0.91X1.22MV0	3' * 4'
SSFDMDM1.5X1.67M1V0	5' * 4'
SSFDMDM1.66X1.22MV0	5.5' * 4'
SSFDMDM1.8X1.22M1V0	5.5' * 5'
SSFDMDM2X2.28M001V0	9.8' * 5'
SSFDMDM2X2M000001V0	6.5' * 6.5'

Parts List

Serial No.	Item	Qty	Icon
1	Plastic Expansion Screws	8	
2	Self Tapping Screws	8	
3	Expansion Screws	2	
4	Wall Fittings	1	
5	Padlocks	1	

Product diagrams



Note: Product images are shown for display purposes only and may not be representative of the final product.

Using Step

- Step 1:** Unpack the product and take it out. Place the retractable door in the position where it needs to be used. Open the hinges, position them in the actual position on the wall and punch the holes.
- Step 2:** Place the plastic expansion screws (Serial No.1 in the parts list) in the perforated position, hold the door in place and fix it with the self-tapping screws (Serial No.2 in the parts list).
- Step 3:** Pull the telescopic door into position and remove the wall fittings (Serial No. 4 in the Accessories List, positioned vertically, refer to the parts List for placement).
- Step 4:** Attach the clips on the side posts to the wall fixings and position them in a sensible position and make the holes again. Place the expansion screws (Serial No. 3 in the parts list) in the holes to fix the wall fittings to the wall.

Caution: Keep hands and fingers out of moving diamonds of web when handling gate.

OPERATING  
INSTRUCTIONS  
&  
PARTS MANUAL  
(OIPM)

Folding Gate - **Double Door**


Check product SKU codes and sizes

SKU	Product Stretching Size
SSFDM1.5X3M0001V0	7.5' * 6.5'
SSFDM2X3.66M001V0	12' * 6.5'

Parts List

Serial No.	Item	Qty	Icon
1	Plastic Expansion Screws	16	
2	Self Tapping Screws	16	
3	Keys	1	

Product diagrams



Note: Product images are shown for display purposes only and may not be representative of the final product.

Using Step

**Step 1:** Unpack the product and take out the 2 retractable doors. Install the telescopic door on one side first. Place the retractable door in the position where it needs to be used. Open the hinges, position them in the actual position on the wall and make the holes.

**Step 2:** Place the plastic expansion screws (Serial No.1 in the accessories list) in the perforated position, hold the door in place and fix it with the self-tapping screws (Serial No.2 in the accessories list).

**Step 3:** Install the telescopic door on the other side as described above.

**Step 4:** Pull the two telescopic doors into position, turn the clasp on the middle side post, fasten it to the lock and lock the door with the key.

Caution: Keep hands and fingers out of moving diamonds of web when handling gate.