



Item #1005250832  
Model #HDTRP6DG

Item #1005172360  
Model #HDTRP6BK


# USE AND CARE GUIDE

## INTERLOCKING GARAGE FLOORING

Questions, problems, missing parts?  
Before returning to the store, call  
Husky Customer Service  
8 a.m. - 7 p.m., EST, Monday - Friday  
9 a.m. - 6 p.m., EST, Saturday

1-888-HD-HUSKY

HUSKYTOOLS.COM



---

### THANK YOU

*We appreciate the trust and confidence you placed in Husky through the purchase of this garage flooring. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Husky!*

Table of Contents

Safety Information ..... 2

Warranty ..... 2

Pre-Installation ..... 3

Preparing for Installation ..... 3

Testing for Below Grade Installation ..... 3

Types of Subfloor Application ..... 3

Adhesives ..... 3

Tools Required ..... 3

Package Contents ..... 3

Installation ..... 4

Clean and Prep Subfloor ..... 4

Layout Tiles ..... 4

Connecting Tiles ..... 4


Tile Installation ..... 4

Cut to Fit ..... 5

Care & Maintenance ..... 5

Cleaning ..... 5

Safety Information



**WARNING:** THIS PRODUCT CAN EXPOSE YOU TO CHEMICALS, INCLUDING LEAD, WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER AND BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM. *For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)*

Warranty

LIFETIME WARRANTY

If your Husky product ever fails, bring it back and we will replace it Free. This full warranty gives you specific rights and you may also have other rights, which vary from state to state. For details on this full warranty, visit your nearby store or call 1-888-HD-HUSKY.

Pre-Installation

PREPARING FOR INSTALLATION

**IMPORTANT:** Floor tiles must be stored in a moist-free environment at a minimum of 65°F and not in direct sunlight for a minimum of 48 hours prior to installation. The subfloor should be the same temperature as well.

- ❑ Keep all tiles away from direct sunlight before and during installation to avoid expansion and contraction.
- ❑ After installation, allow the floor to have enough time to normalize to a fully expanded condition prior to placing permanent heavy fixtures such as: safes, cabinets, workbenches and shelving units.
- ❑ This product can be installed on or above grade level. Installations below grade level require the concrete floors to be clean and free from all moisture and must remain so after the installation is complete.

TESTING FOR BELOW GRADE INSTALLATION

- ❑ Tape a thin 18” x 18” plastic film and leave in place for 24 hours.
- ❑ If excessive moisture appears on the plastic film, the subfloor should be sealed prior to installation. Always use a sealer rated and warranted to seal below grade applications.

TYPES OF SUBFLOOR APPLICATION

Make sure all subfloor surfaces are level and clean from any debris or residue prior to installation.

- ❑ **Concrete Surfaces:** Best used on level indoor concrete surfaces (not recommended for outdoor use).
- ❑ **Wood or Laminate Flooring:** Use caution when installing as moisture could be trapped between surfaces and cause damage.
- ❑ **Tile Flooring:** Can be install over tiles, be aware any raised patterns from tile surface could transfer to PVC flooring.


ADHESIVES

This is a floating floor, therefore adhesives are not recommended for use with HUSKY Interlocking Garage Floor tiles.


Application exceptions where adhesives may be warranted include:

- ❑ Sloped areas such as angled ramps, etc.
- ❑ Areas where the tile will not conform to irregular (curved or other) surfaces.
- ❑ Vertical wall spaces.

TOOLS REQUIRED



PACKAGE CONTENTS



Part	Description	Quantity
A	HUSKY Interlocking Garage Flooring (Tiles)	X6

# Installation


## 1 Clean and Prep Floor Surface

- Store tiles in a moist-free environment at a minimum of 65° F for at least 48 hours prior to installation.
- Ensure that the floor surface is smooth, level, dry and clean. Patch or fill any large holes.



## 2 Layout Tiles


- Lay tiles (do not connect) out across front of garage with teeth pushed against door track.
- Add a row down the middle to determine where the sides and back end. Leave the same distance to the wall on each side. (\*A = less than 9")



## 3 Connecting Tiles


- Align each tooth of the adjoining tile and lightly tap with a rubber mallet (do not use a regular hammer).

**NOTE:** If a tooth does not set all the way, use the wood handle to push and turn the tooth in.



## 4 Tile Installation

- Make sure the front row is straight and square, continue to fill in the rest of the tiles by working from left to right and front to back.





# Installation

## 5 Cut to Fit

- Fill in tiles on both sides and rear by cutting each tile to fit with a utility knife.
- It is critical that a 1/4" to 1/2" gap from each wall for expansion and contraction.
- Trace a pattern for cutting irregular shapes.



**NOTE:** Optional HUSKY Interlocking Garage Flooring Trim Kits can be found on HomeDepot.com ITM # 1005172364; ITM # 1005172363.



# Care & Maintenance

- Avoid prolonged sun exposure to prevent color fading and warpage.
- This product is NOT recommended for exterior installations or applications that are exposed to continuous moisture and or grease.

## CLEANING

- Clean dirt and/or debris by sweeping, vacuuming, or using a wet mop.
- Clean soiled surfaces by mopping or scrubbing with mild detergent.
- For heavy cleaning, a rotary scrubber with soft pad or nylon brushes should be used.



Questions, problems, missing parts? Before returning to the store,  
call Husky Customer Service  
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

**1-888-HD-HUSKY**

**HUSKYTOOLS.COM**

Retain this manual for future use.