

CUSTOMER RESPONSIBILITY

- Frequently inspect all fasteners - they must be tight!
- Lubricate the disk bearings through grease fittings (7), shown on the parts list, before each disk operation and at four-hour intervals during use.

NOTE: When lubricating bearings, it is recommended that you use automotive-type chassis lube.
