

Arcade1Up® Arcade Machine

Instructions / Assembly · Use & Care · Warranty

Instructions / Assembly Unpack all components carefully and verify that all parts are included. Assemble the cabinet following the general order shown in the diagrams provided with your unit. Tighten hardware gently; do not overtighten. Connect internal wiring harnesses as labeled. Place the machine on a level surface before first use. Use & Care Operate the machine indoors in a dry, temperature■controlled environment. Clean exterior surfaces with a soft, dry or slightly damp cloth. Avoid using chemical cleaners, abrasive pads, or excess moisture. Periodically check that fasteners remain secure. Warranty This product includes a limited warranty covering defects in materials and workmanship. Warranty terms vary by region and product model. Proof of purchase is required for any warranty service. Contact customer support for assistance with troubleshooting or service options.