


10MM

## INSTRUCTIONS For Folding Wagon

### Set up the wagon




1. Take the plates out of the side storage pocket.




2. Open the bottom velcro and side zipper, and take off the carry bag.




3. Unfasten the belt and push down on the middle of the wagon. Do not use excessive force if the wagon does not open easily.



4. Push the button to pull out the handle.




5. Put the plates on the bottom of wagon.



- Take out the plates, and pull the handle in the middle of the bottom to fold the wagon.

### Fold the wagon

### Correct rolling way



Please unfold the wagon before first rolling!

### WARNING

1. Do not put the wagon near fire or high temperature environment, which may cause damage of plastic parts.
2. Do not use it on uneven surfaces as it may shorten the products life.
3. This product has been designed for storing and transporting only.
4. This product is not a toy for children. Do not sit in it.
5. This wagon holds a maximum of 200LBS/90.9KGS. Exceeding maximum capacity limit may cause damage to product.
6. Please secure all goods in it to avoid anything dropping. Do not run or rush when moving.
7. Exert care when assembling/disassembling so that fingers are not pinched.
8. Do not store the product outside, which may cause damage to frame or plastic parts.
9. Please remove dirt and contents after use.
10. If the fabric becomes dirty, please clean with a light, cleaning agent.

PATENT NO. US9,073,564B2

10MM

170MM

132MM

PATENTAR NO.US9,073,564B2


10MM

170MM

## INSTRUCCIONES del carro plegable

132MM


1. Preparació n del carro
2. Abra las plazas del bolísono lateral de bolsillo inferior y la cremaillaera lateral, quite la bolsa de transportar.
3. Afloje el中国传统 haga presión hacia abajo en el medio del carro. No utilice demasiada fuerza si el carro no se abre con facilidad.
4. Plegue el carro



## ADVERTENCIA

1. No despegue el carro si lleva a personas con alas tempestruas que daña las piezas plásticas podrían dañarse.
2. No lo utilice sobre superficies con baches ya que podría rebotar la vida útil de los productos.
3. Este producto tiene diseño solo para amueblamiento y sábanas.
4. Este producto no es un juguete para niños.
5. Este carro soporta un máximo de 200 lbs/90.9 kg.
6. Si se excede la capacidad máxima podría causar daños al producto.
7. Tenga cuidado con los dedos al ensamblar/desenambar para evitar que queden atrapados.
8. No almacené el producto en exteriores ya que la estructura o las piezas plásticas podrían dañarse.
9. Quite la suciedad y los contenidos antes de usarlo.
10. Si la tela se ensucia, limpíela con un agente limpia todo suave.

**Despliegue el carro**  
antes de acarrearlo



**Forma correcta de acarreo**