

PART #	KEY # DESCRIPTION
APW5006-01-MT	1 HANDLE ASSEMBLY
W1800-02-MT	2 POWER CORD
W1800-03-MT	3 CONTROL HANDLE
W1800-04-MT	4 WHEEL
W1800-05-MT	5 MOTOR COVER
W2000-06-MT	6 GUN HOLDER
APW5006-07-MT	7 FRONT CASE
APW5006-08-MT	8 REAR CASE
W1800-09-MT	9 SWITCH CASE
W1800-10-MT	10 SWITCH ROD
HDW-AA-08	11 O-RING (7 MM)
IGN-03R-JD	12 ENGINE ON/OFF SWITCH (RED, 4-WIRE FLAT)
W1800-11-MT	13 SWITCH KNOB
W1800-12-MT	14 RUBBER BAND
W2000-13-MT	15 MOTOR & PUMP ASSEMBLY
W1800-14-MT	16 WATER INLET
W1800-15-MT	17 WATER INLET FILTER
W1800-16-MT	18 CLIP COVER
W1800-17-MT	19 GUN
W1800-18-MT	20 WAND
W2000-18-MT	21 WAND (SPECIAL)
W2000-19-MT	22 HIGH PRESSURE HOSE (2320 PSI SPECIAL)
W1800-20-MT	23 QUICK CONNECT
W2000-21-MT	24 DETERGENT DISPENSER
W1800-24-MT	25 DETERGENT HOSE
W2000-26-MT	26 BOTTLE HOLDER
W2000-27-MT	27 WINCH ASSEMBLY
W2000-28-MT	28 HIGH PRESSURE HOSE (2320 PSI SHORT)
HDW-T-M3X20	29 SELF-TAPPING SCREW (M3X20X1.5)
HDW-T-M4X12	30 SELF-TAPPING SCREW (M4X12X1.5)
HDW-T-M4X25	31 SELF-TAPPING SCREW (M4X25X1.5)

HYPL

- [APW5006 PARTS-02](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-02](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)
- [APW5006 PARTS-01](#)

NOTES

BOTH FRONT & REAR PCS INCLUDED