


Hanging Banner with Garden Flag Stand Instruction Sheet


Product Details:

- A. 1 Battery Operated Lighted Banner
- B. 3 Part Garden Flag Stand
- C. 1 Remote Control

Assembly Instructions:



1. Assemble the garden flag stand by connecting all three pieces together. Twist tightly to lock the pieces into place.



2. Unzip the pocket on the banner, located on the back bottom. Put 2 AA batteries into the battery pack, place back into pocket, and zip close.



3. Place banner on to the hook, by sliding the hook into the top holes on the back of the banner. Push the ground stakes all the way into the ground.

Helpful Tips:

- Outdoor use.
- Weather resistant.
- Use the remote control to turn the lighted banner LEDs on and off.
- Make sure the two bottom spikes are fully in the ground and hidden.



Scan the code or visit our website for more information.

www.lumabase.com