


USE AND CARE GUIDE

HAMRICK INDUSTRIAL ADJUSTABLE HEIGHT BAR STOOL



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

We appreciate the trust and confidence you have placed in Stylewell through the purchase of this Hamrick Industrial Adjustable Height Bar Stool. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

Table of Contents

Table of Contents	2
Safety Information	2
Warranty	
1 Year Warranty	
What is Covered	2
What is Not Covered	2
Pre-assembly	3
Planning Assembly	
Tools Required	3
Hardware Included	3

DANGER

- □ Keep small parts away from children during assembly.
- □ Read and follow instructions carefully.



- $\hfill\square$ Read these instructions carefully and keep in a safe place.
- □ TO GUARANTEE THE SAFE USE OF THIS PRODUCT, FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL.
- □ Adult assembly required.
- □ Small parts may present choking hazard prior to assembly.

Pre-assembly (continued)	4
Package Contents	
Assembly	5
Maintenance	7
Care and Cleaning	.7
Troubleshooting	.7

- □ Do not use power tools to assemble your furniture. Power tools may strip or damage parts/product.
- Do not overtighten connectors (screws, bolts, etc.).
 Overtightening can lead to product damage.
- Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact THE HOME DEPOT to obtain any missing parts.
- □ DO NOT USE SUBSTITUTE PARTS.
- $\hfill\square$ This product should only be used on a flat, level surface.
- Product is designed to hold 200 lbs for stools. Exceeding this limit may damage the product or cause injury to the user.
- □ Assembly requires two people; assembly alone may cause injury.

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

This warranty does not cover commercial use, acts of nature, and abusive use.

Pre-assembly


PLANNING ASSEMBLY

Ensure all parts and components are present before beginning assembly. Assemble on a soft, smooth surface to prevent damage to product finish. Do not overtighten screws and bolts to avoid stripping.



NOTE: D0 NOT use power tools.


HARDWARE INCLUDED



ιαπ	naiuwaie iist	Quantity
AA	Bolt 1/4 x 12 mm	8
BB	Bolt 1/4 x 15mm	4
CC	Bolt 1/4 x 35mm	8
DD	Allen Wrench	1
EE	Flat Washer	4
FF	Spring Washer	4

Pre-assembly (continued)

PACKAGE CONTENTS



Part	Part Description	Quantity
Α	Chair back	1
В	Screw post	1
C	Small ring	1
D	Stool legs	4
E	Large ring	1


Assembly

Attaching the legs

Attach legs (D) to the screw post (B) with bolts (AA). Tighten with Allen wrench (DD) after all bolts are completely lined up and inserted into the holes.





NOTE: Do not full tighten bolts completely until assembly is complete.



2 Attaching the large rings


□ Attach the large ring (E) to the legs (D), with bolts (AA) and tighten with Allen wrench (CC).






3 Attaching the small ring


☐ Attach the small ring (C) to the legs(D) with bolts (CC), Tighten with Allen wrench (DD) after all bolts are completely lined up and inserted into the holes.






Attaching the stool legs

□ Put the seat with back (A) on a soft, smooth surface and attach the pre-assembled leg frame with flat washer (EE),spring washer (FF)and bolts (BB). Tighten with Allen wrench (DD) after all bolts are completely lined up and inserted into the holes.






Assembly (continued)

5 Tightening the bolts

□ Put the stool on a level surface and fully tighten all bolts previously tightened with Allen wrench. Tighten all the bolts on a level surface.



NOTE: If the stool legs are not on the floor: You can adjust levelers properly (on the bottom of the legs). You may need to loosen the bolts. Apply some weight on the table to get all legs on the floor, and then tighten the bolts at that positon.



Maintenance

 $\hfill\square$ Check bolts/screws periodically and tighten them if necessary.

Care and Cleaning

- Dust this item regularly with a soft, lint-free cloth to prevent soil buildup.
- Wipe away spills immediately to prevent staining using a clean cloth dampened with water.
- Do not use liquid or abrasive cleaners on the metal frame, as this may damage the finish.

Troubleshooting

Problem	Solution
Not all of the product's legs touch the floor.	Make sure adjustable center feet levelers are adjusted properly. The levelers are pre-assembled on the bottom of the legs.
	The product is KD construction. You may need to loosen the bolts and place the product on a flat surface. Ensure that the legs all touch the flat surface and then re-tighten the bolts.
	Loosen all the bolts and apply some weight to the product to get all the feet to touch the floor. Then re-tighten the bolts in that position.
One or more of the bolts do not fit in the holes correctly.	The product is KD construction. Do not fully tighten the bolts before all the bolts are completely lined up and inserted into holes. Loosen the bolts and make sure all bolts are lined up and inserted into the holes.



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.