




Replacement Parts List

Touchless Single-Handle Pull-Down Sprayer Kitchen Faucet
with LED Light in Stainless Steel

MODEL	STORE SKU #	FINISH
67536-0508D2	1001407752	Stainless Steel



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Spray head and Hose	RP3822308D2	207093791	
2	Wearable ring	RP70380		
3	O-ring	RP60071		
4	Cartridge	RP20005	207093806	
5	Bonnet	RP70394		
6	Cap	RP8002808D2		
7	Handle	RP1336808D2		
8	Screw	RP50015	207093810	
9	Index & O-ring	RP8044008D2		
10	Washer	RP64239		
11	Nut	RP56098		
12	Cap	RP70448		
13	Block	RP70421	207093811	
14	O-ring	RP60002		

Part	Description	Part #	Internet SKU #	Store SKU #
15	Quick connect assembly	RP70482	207093811	
16	O-ring	RP60089		
17	Weight clip	RP64204	207093823	
18	Weights	RP70441		
19	Escutcheon	RP8044108D2		
20	Gasket	RP80442		
21	Control box	RP70515	207093817	
22	Battery pack	RP70514	207113905	
23	Pump kit	RP46022		
24	Flange kit	RP4606608D2		
25	Bottle	RP46060		
26	Soap dispenser	RP4606508D2	207113918	