

Replacement Parts List



A (x4)



J1 (x4)




B (x2)



J2 (x4)




B1 (x2)



K (x1)




B2 (x2)



K1 (x1)



C (x2)



L (x4)



C1 (x2)



M (x4)



C2 (x2)



N (x4)



D (x2)



D1 (x2)




D2 (x2)




E (x2)



E1 (x2)



E2 (x2)



F (x4)



G (x4)










H (x4)













H1 (x4)

ITEM	DESCRIPTION	QTY
A	Pole	4
B	Beam	2
B1	Joint Bar	2
B2	Sidewall Track	2
C	Beam	2
C1	Joints Bar	2
C2	Sidewall Track	2
D	Beam	2
D1	Joints Bar	2
D2	Sidewall Track	2
E	Beam	2
E1	Joints Bar	2
E2	Sidewall Track	2
F	Union Bar	4
G	Corner Cover	4
H	Joint Cover	4
H1	Joint Cover	4
J1	Corner Solidifying Bar	4
J2	Corner Solidifying Bar	4
K	Inside Roof Connector	1
K1	Outside Roof Connector	1
L	Base	4
M	Corner roof bar	4
N	roof bar	4



ITEM	DESCRIPTION	QTY
P	Finishing Bar	2
P1	Net Frame	2
Q	Finishing Bar	2
Q1	Net Frame	2
Q2	Net Frame	2
R	Finishing End	8
S	Spacer	96
T1	Finishing Bar	2
T2	Finishing Bar	2
U1	Solidifying Bar	2
U2	Solidifying Bar	2
U3	Solidifying Bar	2
U4	Solidifying Bar	2
U5	Iron Angle	4
U6	Iron Angle	4
V1	Roof Panel	2
V2	Roof Panel	2
V3	Roof Panel	2
V4	Roof Panel	2
V5	Roof Panel	2
V6	Roof Panel	2
W3	Roof Panel	2
W4	Roof Panel	2
W1	Roof Panel	2
W2	Roof Panel	2
W5	Roof Panel	2
W6	Roof Panel	2
X4	Roof Panel	2
X5	Roof Panel	2



ITEM	DESCRIPTION	QTY
X1	Roof Panel	2
X2	Roof Panel	2
X7	Roof Panel	2
X8	Roof Panel	2
X3	Roof Panel	2
X6	Roof Panel	2
Y	Mosquito Sidewall	4
Y1	Solid Sidewall	4
Z	Metal Bracket	56
Z1	Metal Bracket	4
Z2	Metal Bracket	4
Z3	Metal Bracket	4
Z4	Metal Bracket	4
1#	Screws	206+3
2#	Screws	16+2
3#	Screws	16+2
4#	Hook	104
5#	Screws	64+3
6#	Screws	8+1
7#	Screws	28+2
8#	Screws	4+1
9#	Screws	24+2
10#	Screws	4+1
11#	Screws	8+1
	Allen key	2
	Wrench	2