

Replacement Instruction for Casters

WARNING

-
- DISCONNECT ELECTRICAL POWER TO COOLER BEFORE REPLACING THE CASTERS.
 - CASTER INSTALLATION MUST COMPLY WITH COOLER MANUFACTURER'S SPECIFICATIONS AND APPLICABLE ELECTRICAL AND BUILDING CODES
 - USE ONLY IN UPRIGHT POSITION.
-

