

General Use and Care Manual for Folding Tables

Introduction

Folding tables are versatile, space-saving additions to any home, patio, or event space. Whether used for dining, entertaining, or extra workspace, proper care ensures longevity and safe operation. This guide provides universal tips for maintaining and using folding tables effectively.

Safety Guidelines

- **Weight Capacity:** Always adhere to the table's weight limit (typically 50–150 lbs, depending on size and material). Distribute weight evenly to avoid stress on the frame or surface.
- **Stability First:** Set up the table on a flat, level surface. Ensure all legs are fully extended and locked into place—never use a table that wobbles or has loose hinges.
- **No Standing or Climbing:** Folding tables are not designed to support human weight. Never stand, sit, or climb on the table, as this may cause collapse or damage.
- **Folding Caution:** Keep hands, fingers, and loose clothing clear of hinges when opening or closing. Avoid forcing the table to fold/unfold—if it resists, check for obstructions.

Setup & Folding Tips

- - **Unfolding:**
 - - i. Lift the table by its frame (not the surface) to avoid bending.
 - ii. Slowly extend the legs until they lock into position (listen for a “click” if equipped with locking mechanisms).
 - iii. Test stability by gently pressing down on opposite corners before use.
 - **Folding for Storage:**
 - - i. Remove all items from the tabletop first.
 - ii. Release leg locks (if applicable) and fold legs inward slowly.
 - iii. Store in a dry, clean area away from direct sunlight, extreme temperatures, or moisture.

Cleaning & Maintenance

-

Surface Care:

-
- **Wood/Acacia:** Wipe with a soft, damp cloth and mild soap for spills. Dry immediately to prevent warping. Avoid harsh chemicals—use wood conditioner annually to preserve finish.
- **Metal/Aluminum:** Clean with a damp cloth; use a mild detergent for stains. Dry thoroughly to prevent rust. Polish occasionally with metal cleaner to maintain shine.
- **Plastic/Rattan:** Wipe with soap and water; avoid abrasive tools that scratch. For outdoor use, rinse with a hose and air-dry.

•

Hinge & Frame Maintenance:

-
- Inspect hinges and locks monthly for debris (dirt, food crumbs). Brush away buildup with a soft brush.
- Lubricate hinges annually with silicone spray or beeswax to prevent stiffness. Wipe excess lubricant to avoid attracting dust.

•

Weather Protection:

-
- For outdoor use, cover tables with a waterproof cover when not in use. Store indoors during extreme weather (snow, heavy rain, high winds).

Storage Best Practices

- Fold tables completely to save space—avoid propping them against walls at an angle, which can warp the frame.
- Keep stored tables away from sharp objects or heavy items that may scratch or dent surfaces.
- For long-term storage, clean the table first and place it in a well-ventilated area to prevent mold or mildew (especially for wood or fabric surfaces).

Troubleshooting Common Issues

- **Wobbling:** Tighten loose screws or adjust leg height (if adjustable). Place a flat pad under uneven legs.
- **Stuck Hinges:** Clean with a dry cloth and apply lubricant. Avoid forcing—this may break the mechanism.
- **Surface Stains:**
 - For wood: Use a paste of baking soda and water; gently rub and wipe clean.
 - For metal/plastic: Use a mixture of vinegar and water to dissolve tough stains.

By following these simple steps, your folding table will remain a reliable, functional asset for years, adapting seamlessly to parties, meals, work, and more.

