

USE AND CARE

NOTE:

- ① Avoid damage to tines. Do not tow the aerator across concrete or asphalt driveways and walkways.
 - ② Excessive towed load can cause loss of control on slopes. Stopping distance increases with speed and the weight of the towed load.
 - ③ Total towed weight must not exceed combined weight of towing vehicle, ballast and operator.
 - ④ Do not allow children to operate the towing vehicle. Do not allow adults to operate the towing vehicle without proper instruction or without having read the owner's manual.
-

CARE AND STORAGE:

After the first 30 minutes of use, please check all fasteners for tightness. Tines are manufactured with galvanized steel to resist wear of abrasive soil. Striking objects can cause tines to curl or break. Apply a light coat of oil on tines after use to prevent rust.

Store Aerator on the ground or low to the ground with tine points facing the wall or ground. Do not store Aerator hanging from the wall, ceiling or with Tine points facing outward.