

Installation Guide

1. Before you start using expandable hose, ensure to firmly affix the rubber inside(already installed) the female coupling to prevent leaking.
2. Append the female end of the expandable hose to the water source.
3. Turn the water on at the source. Gradually increase the water pressure.

The hose will automatically expand up to 3 times its original length.

4. When the hose is fully expanded, use the hose like any ordinary garden hose.

Note: When used without a spray nozzle, the hose will contract several feet or more when the water is turned on.

5. After use, turn the water off at the water source.
6. If you are using a nozzle then open the nozzle. As the water begins to drain from the hose, it will automatically contract back.

SAFETY WARNINGS

1. Intended for outdoor watering applications only
2. Not for hot water use
3. Do not leave under pressure when not in use
4. Do not leave unattended children to use it
5. Do not leave out on freezing temperatures
6. Store indoors in winter