


Battery Indicators

ML-F004-L

User Manual



Product Features:

- ❶ Adopts brushless motor, it is powerful with low energy consumption and noise. There are 3 speed settings: breeze / strong wind / super strong wind. It has 3 high-end aerodynamic blades which make the airflow very strong.
- ❷ It is lightweight and portable. With a 360° rotatable fan head, it can blow in the direction you want. It is a rechargeable fan with light and a hook, suitable for camping, beach, RV, treadmill, table top, office, home, etc.
- ❸ It has an LED light with 3 adjustable brightness and a foldable hook as well. The LED light is composed of 36 light beads, hence powerful lighting. The fan and LED light can be controlled separately, very convenient for you to operate.
- ❹ Built-in high energy density battery, which has a large capacity of 10000mAh. The maximum working time of the fan is about 7 hours at speed 3. And it has a timer function, too.
- ❺ Equipped with USB-C port for fast charging. When the device is out of power, you could also connect it via the included USB cord for power supply. You can use the device during charging. The input current is 2A. It is compatible with computer or any ordinary USB port. Built-in charging protection integrated circuit, safe and reliable.
- ❻ The grid of the fan is small enough to prevent fingers from getting through it. It will auto stop when small sticks fall into the fan, totally safe!

Product Model	ML-F004-L
Input	5V/2A
Power	8W
Battery Capacity	10000 mAh
USB Port	Type-C
Speed Setting	High / Medium / Low
LED Power	2.5W
LED Illuminance	740LM at level 3
Charging Time	6-6.5H
Battery Indicators	25%, 50%, 75%, 100%
Battery Life	About 7-28H
Size	21.4*9.8*3.3 inch (544*250*85mm)
Weight	28.7 oz. (815g)

Packing List:

8” Clip-On Lighting Fan*1, USB-C Cord*1, User Manual*1

How to Use:

- ❶ Fan control: Short press the fan speed button to switch among speed 1/2/3/OFF. Long press this button to turn it off at any speed.
- ❷ LED control: Short press the LED brightness button to switch among level 1/2/3/OFF. Long press this button to turn it off at any brightness level.
- ❸ Timer control: Short press the timer button to switch among 3 timers of 1/2/5 hours in turns.
- ❹ This device can be 360° adjusted, and used on table top, in tents, as a handheld fan, etc.
- ❺ Please use 5V/2A adapter (NOT included) for charging.

Charging & Display:

- ❶ Please use 5V/2A adapter (NOT included) for charging. Inadequate input may cause slow charging or not working. The device can work on the lowest setting during charging.
- ❷ Designed with low battery protection, it will flash in red for 3 seconds at low battery and then turn off automatically.
- ❸ There are 4 LED indicators on the fan which indicate battery level of 25%, 50%, 75%, 100%; the LED indicators flash in blue during charging, and will be solid blue when fully charged.
- ❹ When the fan / LED light are working, the blue indicators of corresponding battery level is on; when the battery level gets lower, the corresponding battery indicator will be off and the indicator of lower battery level is on; the battery indicators will be off when turning off the device.

Display Status	Meaning
Flash in red	Low battery, it will stop working after 3 seconds.
Blue lights on	On working, indicate corresponding battery level.
Blue lights flash	On charging, the 4 indicators will be solid blue when fully charged.
Indicators off	OFF

Attentions:

- ❶ Please do not squeeze or detach the battery or place the fan in high temperature (60℃ or above) for a long time, otherwise it may be at the risk of leakage or explosion.
- ❷ When the fan is working, please do not put your fingers or any foreign objects into the fan for the sake of your safety.
- ❸ Please do not clean the fan with hard metal or corrosive liquid. Please do not disassemble the device.
- ❹ Please store the fan out of the reach of children. The fan should be used by children under the supervision of adults.
- ❺ When the fan is not used for a long time, it should be charged every 2-3 months and stored in cool and dry place.
- ❻ Please do not use the fan in humid environment.

Warranty card

Dear customer, thanks you for purchasing our company's products.
Please read the instruction manual and save it for future reference.
Please fill out the warranty card and place it in the mail.

Customer name:
Address:
Date of purchase:
Phone number:
Email:
Product model#:



正面

反面