



STOVETOP ALUMINUM POPCORN POPPER

ITEM: 96001



OWNER'S MANUAL AND SAFETY INSTRUCTIONS

SAVE THIS MANUAL: KEEP THIS MANUAL FOR SAFETY WARNINGS, PRECAUTIONS, ASSEMBLY, OPERATING, INSPECTION, MAINTENANCE AND CLEANING PROCEDURES. WRITE THE PRODUCT'S SERIAL NUMBER ON THE BACK OF THE MANUAL NEAR THE ASSEMBLY DIAGRAM (OR MONTH AND YEAR OF PURCHASE IF PRODUCT HAS NO NUMBER).

FOR QUESTIONS PLEASE CALL OUR CUSTOMER SUPPORT: (909) 628 0880 MON-FRI 9AM TO 3PM PST



GENERAL SAFETY WARNINGS

The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator. Read carefully and understand all instructions before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

- **NEVER** leave the popper unattended while in use. Keep out of reach of children.
- Check to be sure the handle is securely fastened to the popper before popping
- Make sure the lid is securely fastened to the kettle before popping.
- **ALWAYS** use caution when the popper is hot.
- Wash your popper in mild, soapy water before and after popping to keep your popper clean.
- Close the lid before popping, remove from the stove when done popping.
- For household use only, do not use this popper for anything other than its intended use.
- **DO NOT** put your face or hands near popper lid when freshly popped to avoid steam burns.
- **DO NOT** put the popper in the microwave oven.
- **DO NOT** put the popper in the dishwasher, wash by hand only.
- **DO NOT** pop popcorn in the popper without cooking oil. Spray oils are **NOT** sufficient for use with the popper.
- **DO NOT** use the popper when there is water in the popper. Doing so will cause the oil to pop.
- **DO NOT** use sugar or cheese as these may burn or explode when heated to high temperature.
- **DO NOT** set an empty popper on a heated stove, doing so can cause damage to the popper.
- **DO NOT EVER** use water to put out an oil fire; use a fire extinguisher or use baking soda instead.
- **NEVER** allow children to use the popper.

OPERATION

PRIOR TO FIRST USE

1. Add one tablespoon of vegetable oil into the popper.
2. Tilt the popper to coat the bottom and sides.
3. Heat for 20 seconds or until the oil is hot. **DO NOT** leave the popper unattended.
4. Remove the popper from the stove and let it cool down.
5. Wipe out the oil in the popper with the napkin and you can start popping.

POPPING POPCORN

1. **DO NOT** add any ingredients while the popper is on any heat source.
2. Use the proper amounts of popcorn and oil. 1/2 cup popcorn and 1/3 cup of oil.
3. Hybrid popcorn such as white, crimson or petite pop up smaller and should be adjusted accordingly.

POPPING PROCESS

1. Assemble the pot and lid.



2. Place the assembled popper on the stove and heat at medium heat for about a minute.



3. Open the lid and add the oil into the pot.



4. Close the lid and stir the popcorn with the poppers handle for about three minutes.



WARRANTY

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Record Product's Serial Number Here: _____

Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only and are not available individually as replacement parts.



SAVE THESE INSTRUCTIONS.



Questions, Problems or Missing Parts?

Before returning to a retailer, our exceptional customer service is available to help.

Call Us: 909.628.0880

Hours of Operation: 9 to 4pm PST, Monday - Friday

Email: customer@bartonliving.com

PRODUCT MADE IN CHINA