

Usage Instructions

Step 1: Set the Steam Level

- **Low Steam:** Ideal for light cleaning tasks or for delicate surfaces.
- **Medium Steam:** Use for general cleaning of tiles and hardwood floors.
- **High Steam:** Use for heavy-duty cleaning, including stubborn dirt, stains, and grease.

To adjust steam settings, turn the steam control dial or use the steam trigger on the handle, depending on your model. The unit will begin to emit steam after a few moments of heating.

Step 2: Begin Cleaning

- **For Hardwood and Tile:** Move the mop across the floor in a slow, steady motion. Let the steam penetrate and loosen dirt and grime.
- **For Carpeted Areas:** Attach the **Carpet Glider** to the mop head. This helps prevent the mop from damaging carpet fibers while ensuring steam is distributed evenly.
- **For Stubborn Stains:** Apply extra steam by holding the mop in place for a few seconds.

Step 3: Refill Water Tank (if needed)

If you run out of water during cleaning, simply unplug the mop and refill the water tank.

Step 4: Turn Off and Unplug

Once you are finished cleaning, turn off the steam mop and unplug it from the outlet.

Care & Maintenance

Cleaning the Mop Head and Pads

1. **After each use**, remove the microfiber cleaning pad and rinse it under cold water.
2. **Machine wash the cleaning pads** in warm water (do not use fabric softeners or bleach). Air dry before reattaching to the mop.
3. **Clean the mop head** by wiping it down with a damp cloth. Do not immerse the mop head in water.

Maintaining the Water Tank

1. Empty the water tank after every use to prevent water from stagnating and causing odors.
2. Occasionally clean the water tank with a soft cloth and mild soap to remove any build-up. Avoid using abrasive cleaners that could scratch the tank.

Descaling the Mop (if needed)

If you live in an area with hard water, mineral deposits may accumulate in the steam mop over time. To descale the mop:

1. Mix equal parts **white vinegar** and **water**.
2. Fill the water tank with this solution and let the mop steam for a few minutes.
3. Allow the solution to sit in the mop for 15-20 minutes, then empty the tank and rinse thoroughly with clean water.

Check for Blockages

Periodically check the steam nozzle for any blockages caused by mineral deposits. If blocked, flush with warm water until the nozzle is clear.