#### 12、bath-massage

(1)Press the water switch, turn the select shift, pour " water ".

(2)Water level should be 10-20mm higher than the sprayer.

(3)Pouring enough water, press" atmosphere ", the engine works, and begins to

spouting. During massage, turn on the " air conditioning ".

(4)Press the " atmosphere ",when stop.

(5)After showering, turn on the "draining switch "to drain water.

#### 13、sole-massage

Set the sole-massage to a suitable place, and turn the select shift to solemassage, then press the water switch. Test the water temperature and begin massage. Press the water switch again and stop.

#### $14\tar{s}$ turn off the tap

After using, turn the select shift to the original place. Press the water switch. at last power off.

#### ATTENTION

- 1. Please install and operate this product according to this manual.
- 2. Please fix reliable earth line and electric leakage protection device.
- 3. Please install general switch for power supply and water supply.
- 4. People with hypertension or drunk are not allowed to have sauna steam bath.
- 5. Children should have sauna steam bath under adult's instruction.
- 6. Please don't pour corrosive liquid into this sauna steam room.
- 8. Pay attention to the steam sprayer and water tank drainage, they are in high temperature while working.
- 9. please be ware of the step and never put finger into the door gap in case of accident.
- $10.\;$  Never knock the room with hard and heavy materials, in case of damage.
- 11. never smoke in the room in case of fire.
- 12. clean up the room after finish taking shower, in case of slippery surface.
- 13. when there is plastic strip is worn-out, please replace it as soon as possible in case of water leaking.
- 14. clean the bottom bathtub with toothpaste if there is some dirt.
- 15. please keep the bottom clean, in case of some waste stuck into the drainage.
- 16. never hang heavy things up the handle.
- 17. We don't take the responsibility for those damage caused by illegal operations.
- 18. Please dispose of this product according to native law when it is out of use.
- 19. Please contact our dealer for help if you have any problems.



Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

# Install manual Steam bathroom






# **INSTALL GUIDE**

1. Check if all the parts complete. 2.Set all the parts to right places, and make balance. 3.Set the parts according to the diagram. 4.After step3, power on and test.

# THE TECHNIQUE PARAMETER OF THE PRODUCTS

- 1. Voltage: AC220V-240V 50Hz/60Hz
- 2. Water Volatge: 0.1~0.2Mpa
- 3. Power of steam generator: 3000W
- 4. Power og water pump: 1HP
- 5. SIZE: 1600x1600x2250 mm



CONTROL PANEL

# **OPERATION METHOD**

#### 1, power on

Connect to the power, press (), and the top lamp is on. The screen shows all the patterns in 2 seconds and begin to test. Resume in 3-6 seconds.

meter.

.refullv

## 2、lamp

Press (17), the top lamp and wall lamp turn on. The screen shows a lamp pattern. If you want to turn it off, press (17) again.

#### 3、steam

(1) Press (1), the screen shows a steam pattern and begin to work, and water pour into the system. After about 1 minute, steam comes out. If running short of water, it will supply automatically. (2) Time and temperature selection: Press (4)6, (1) to select the time or temperature function. Then press  $(\mathbf{v}_3)$ ,  $(\mathbf{A}_4)$  to set the time or temperature. The time arrange is 5-60minutes. The arrange of temperature is 30-60°C.

## 4. ozone disinfection

Press (A5), and begin to disinfect. Press (A5) again and stop. If disinfecting for 10min, it will stop automatically.

Note: the ozone sterilization can not use at the same time.

#### 5、fan

Press (3), the fan begin to work. The screen shows a fan pattern, if you want to stop, press (is) again.

#### 6, telephone

(1) Make a telephone call: Press (28), the screen shows a telephone

pattern, then dial. After getting through, speak towards the mic. Press (1), (1) to set the volume.

(2) when the bell ringing, press (2)

(3) After dialing, press (28).

### 7, radio

-Volume ur

-Time and temperatur

-Lamp

(3)

-12 æ

3.the effect of usage distance will be 5

at throw it heavily'don, Please put the remote control c. £

**Remote Control** 

Press (29), choose the radio function. The screen shows a radio pattern, and the voice comes out from the loudspeaker, press (101-\*) or (101+#) to set the frequency. Press (m), (m) to set the volume. Press (P) again and turn off.

8、CD

(1) Press (2.9), the music comes out. The screen shows a "CD" pattern. Press (), (), to set the volume. Press @ again and stop. (2) you should connect the CD player, if choosing this function.

## with computer panel's function 1 to 12. 9, warning

Press the warning voice comes out from the loudspeaker.press again and stop.

# 10, power off


Press (), the screen shuts off. The system drains for 3 minutes, and the screen shows 3 minutes count backwards. Finally, power off the main power source.

## 11, taking shower and water-massage


#### SHIFT VALVE

Press the water switch, and pour water. Get a suitable temperature. According to your need, choose the shower function. The function of the select shift (from right to left) is movable shower bath, big acupuncture watermassage,small acupuncture watermassage,waterfall,and sole-massage shower bath, acupuncture water massage, roof shower bath, movable shower bath, turn the shift and select what you need.






# CONSTRUCTION SKETCH



- 1.
- glass door
  exhaust fan
- 3, ozone
- 4, moveable shower
- 5, speaker
- 6, decorated lamp
- 7, water switch/mixer
- 8, cold/hot water switch
- 9, towel shelf
- 10, nozzle
- 11、body
- 12、body roof




Please install the earth line safely by professional technician.

# 13, roof lamp

- 14, moveable shower
- 15, decorated lamp
- 16, handdrail
- 17, temperature sensor
- 18, soap box
- 19, foot massage
- 20, berb box

24, nozzle

- 21、bottom bathtub
- 22, control panel
- 23、water switch/mixer
- 25, waist -shaped board 26, waist -shaped board
- 1, waterfall
- 2, drainage switch
- 3、water pump swich
- 4, air conditioning
- 5, water in
- 6, water jet
- 7, drainage



SIZE:1600X1600X2250mm

