

Trim-A-Slab Sizing Guide





- Measure one of the cutouts to verify that the template is being printed at full scale
- 2. Cut out along lines
- 3. The wider end should <u>not</u> fit between the slabs
- 4. The narrow end should fit between the slabs



This gap should use the 3/4" size