


## **USE AND CARE GUIDE**

#### **MEGAN 36IN. LARGE ROUND COFFEE TABLE**



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 6 p.m., EST, Monday

1-855-HD-HAMPTON

**HAMPTONBAY.COM** 

#### **THANK YOU**

### **Table of Contents**

Table of Contents	2
Safety Information	2
Set Up Your Furniture Properly	
Examine Your Furniture	2
Observe Weight Limits	2
Warranty	2
What is Covered	
What is Not Covered	2

Pre-Assembly	3
Planning Assembly	
Hardware Included	3
Package Contents	4
Assembly	5
Care and Cleaning	

## **Safety Information**

#### SET UP YOUR FURNITURE PROPERLY

- □ Ensure that all parts are assembled properly and fully tightened as per the instructions.
- When placing in the desired location, ensure that all legs are resting on the same surface.

#### **EXAMINE YOUR FURNITURE**

 Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be re-tightened fully before additional use.

#### **OBSERVE WEIGHT LIMITS**

The weight limits for the following products are listed below:

- □ Chair: 300 lbs □ Sofa: 700 lbs
- □ Swivel Chair: 300 lbs
  □ Loveseat: 500 lbs
  □ Ottoman: 150 lbs
  □ Dining Table: 100 lbs
- Table: 50 lbs Dining Chair: 200 lbs



**CAUTION:** If you overload your furniture, injuries can occur.

### Warranty

#### TWO YEAR FRAME, WEAVE AND FABRIC LIMITED WARRANTY

#### WHAT IS COVERED

We warrant the frame, weave and fabric to be free of manufacturing defects to the original purchaser for two years. For glass table top we warrant 30 days from the date of purchase.

#### WHAT IS NOT COVERED

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty.

We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.


Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Hamptonbay.com.

# **Pre-Assembly**

#### **PLANNING ASSEMBLY**

To prevent damage, place all parts on a soft surface during assembly. Remove all protective caps before beginning assembly.


#### **HARDWARE INCLUDED**



Part	Description		Quantity
AA	Nut	Ф6 mm	8
BB	Washer	Ф6 mm	8
CC	Caps		8
DD	Wrench	#11	1

# **Pre-Assembly (continued)**

#### **PACKAGE CONTENTS**




Part	Description	Quantity
А	Table top	1
В	Legs	4

## **Assembly**


# 1 Attaching the leg

- □ Place table top (A) on a soft surface.
- Put the leg (B) metal side into the hole of top (A).
  Fasten with nut (AA) and washer (BB). Tighten half way using the wrench (DD).




# 2 Attaching the other legs

 $\square$  Repeat step 1 for the other legs.




# 3 Adding the caps

- Check and make adjustments as needed.
- Fully tighten all the nuts (AA) with the wrench (DD) and cover with the nut caps (CC).
- □ Adjust leg levelers as required.



# 4 Completing the assembly

 $\hfill\Box$  This table is now ready for your enjoyment.



5

# **Care and Cleaning**

- □ Before using, wipe with a clean, dry cloth. Do not use bleach or solvents. When not in use, store furniture in a cool, dry place.
- ☐ If your set includes cushions or mesh fabric, they may be cleaned by hand with a mild solution of soap and water. Rinse cushion thoroughly and allow to drip dry. Do not machine wash or tumble dry, as cushions may shrink.
- □ Do not use bleach or solvents on fabrics. When cleaning the table top make sure to use a soft, clean cloth that does not bleed color as well.



Questions, problems, missing parts? Before returning to the store, call Home Depot Customer Service 8 a.m. - 6 p.m., EST, Monday-Friday

## 1-855-HD-HAMPTON HAMPTONBAY.COM

Retain this manual for future use.