

Outdoor Furniture Care/Cleaning Guidelines

Our furniture is designed to be enjoyed for many years, and while the materials themselves are durable, they still need some care to keep them looking great. Follow these simple tips to maintain the function and appeal of these products.

Solid Wood, Veneer, and Painted High-grade MDF – To maintain the attractive coloring of our solid wood, veneered and painted MDF pieces, we suggest cleaning with a dry cloth or with wood furniture cleaners. We recommend using coasters and wiping spills up immediately to avoid excess moisture that could distort the product.

High-grade MDF and Laminate – Keep your product in top condition by dusting with a clean, dry cloth. If more care is needed, apply a small amount of furniture cleaner then immediately wipe dry. Avoid moisture as much as possible.

Tempered Glass – Properly care for this material by wiping down with glass cleaner and a paper towel or soft cloth.

Metal – To keep these products clean and looking sharp, we recommend dusting with a dry or damp cloth. If using a damp cloth, dry immediately afterwards so moisture doesn't settle.

Faux leather – For best upkeep, wipe down with a dry or damp cloth. If leather cleaner is used, we recommend testing an inconspicuous spot before using on the entire surface.

Fabric – To clean fabric on our products we recommend spot cleaning with a damp cloth. Address spills quickly.