



POWERCORNER®

ANGLE BROOM ESCOBA ANGULAR

TO ASSEMBLE PARA ENSAMBLAR

**Press down
and twist
to attach**

Presione hacia
abajo y gire
para sujetar




**Press down
and twist
to attach**

Presione hacia
abajo y gire
para sujetar



**Twist to attach
or detach**

Gire para sujetar
o separar



ocedar.com

a brand of



©2022 Freudenberg Household Products LP
Attn: Consumer Affairs
2188 Diehl Road, Aurora, IL 60502
ocedar.com/contact-page