



BARNEL USA[®]
MANUFACTURER

Instructions & Assembly

B188F2, B188F4, B188F7 Ultra Reach[®] Pruner

B188Z4-6, B188Z6-10 Telescopic Ultra Reach[®] Pruner

INSTRUCTIONS: Place the cut target deep into the jaw and squeeze handle to complete the cut. Do not rip, twist or pull fibers or use extreme force.

CUT-N-HOLD: The Cut-n-Hold feature will clamp the cut stem or branch and remains engaged while you continue squeezing the handle. Adjust using a Phillips-head screwdriver if necessary.

TELESCOPIC FEATURE (B188Z4-6 & B188Z6-10 ONLY): To extend or retract the pruner, release the push button lock at the top of the fixed/outer pole. Slide the inner pole in or out and ensure the lock reengages prior to using.

MAINTENANCE: Fill the center oiler bolt with oil by depressing the center bearing with the oil applicator tip and squeezing oil until full. Always clean sap from the blade and dry entire pruner thoroughly before storing.

⚠ Always use appropriate personal protective equipment.

Refer to the warnings and safety information provided with the product.

Barnel USA[®]

Barnel International, Inc. Portland, Oregon

www.barnel.com info@barnel.com