


How to assemble

1. How to rear shock absorber spring

Turn the car over, take off the screw and washer from the rear shock absorber axle, insert the spring to the axle and use washer and screw to tighten. The other side in the same way.



2. How to assemble rear axle and rear wheel

Put the rear axle through rear shock absorber hole, washer, rear axle casing and rear shock absorber hole. Add washer, motor, rear wheel, washer, use screw to tighten. Add wheel cover finally. The other side in the same way.



3. How to assemble front wheel

Add washer, front wheel, washer to front axle, use screw to tighten. Add wheel cover finally. The other side in the same way.



4. How to assemble buffer beam and window frame

Insert buffer beam and window frame into the right place on the car.




5. How to assemble steering wheel

Take off screw and nut from steering wheel, insert steering wheel to direction lever, use screw to tighten.



6. Connect the lines

Connect motor line and battery line. Turn on the power to check line connected right or not.



7. How to assemble seat, back handrail and flag

Insert seat into the right place on the car, use screw to tighten. Insert back handrail and flag into the right place on the car.



Warning

For children's safety, please read these carefully.

- Assembly and adjustment must be done by adults, keep children away.
- Keep children under 36 months away from small parts.
- Safe belt is a must when children playing. Do not be close to fire.
- Adult must teach how to play it and never leave children alone for playing.
- Do not stand up or play when children are stepping on foot pedal.
- Battery must be charged by adults only. Please charge it first before use.
- Keep children away from plastic bag, or suffocation may occur.
- Only use spare parts which provided by manufacturer.
- Charger is not a toy for playing.
- Maximum loading capacity is 35KG. Do not overload.
- Suitable age: 37-95 months.

Safety use

- Do not play in the street, road, slope or ditch.
- Do not change the line or add electric device to the car.
- Play the car in the dry area, not wet. Keep away from fire, or may damage the line.
- One or two riders one time only. Do not overload.
- Maximum capacity is 35KG.
- Turn power off if no use. If long time no use, unplug battery line.
- Check battery, charger and other spare parts regularly. If any problem, please fix it before playing.

Charging notification

- For the first use, please charge 8-12 hours, or will damage the battery.
- Plug charger DC line into charge hole first, then plug charger into socket. Car can not be played when it charging.
- Every time it charged, do not charge more than 20 hours. It is normal that charger and battery warm (under 60°) during charging.
- Do not charge if plug is wet, or will occur short-circuited.
- Only use charger provided by manufacturer, or will damage charger and battery or occur short-circuited.
- If long time no use, please charge 1 time per month at least.

Charging step

- Step 1: Charge hole is under the seat.
- Step 2: Plug charger DC line into charge hole.
- Step 3: Plug charger into socket.



Warning: Car must be charged by adults only. Car is useless during charging.

Problem solution

| Problem | Analysis | Solution |
|----------------------------------|--|--|
| | Battery low power Fuse protect | Charge battery Reuse a few minutes later |
| Car can not move | Power not turn on Battery line loose Battery damaged Electric device damaged Motor damaged | Turn on it again Reconnect Replace a new one Replace a new one Replace a new one |
| Battery can not be recharged | Battery connector loose Charger not plug in Chager damages | Reconnect Replug Replace a new one |
| Car does not run very long | Battery power low Battery is old | Recharge Replace a new one |
| Charger feels warm when charging | Chemical reaction | Normal |
| Speed slow | Battery is old Battery power low Overloaded Road is not even | Replace a new one Recharge Reduce weight under 35KG Play in a smooth area |

Maintenance instruction

- Check battery, charger and other spare parts regularly. If any problem, please fix it before playing.
- Use lubricating oil to care iron parts. Keep car away from fire and sunshine. Park it on the even place, not reversal or gradient.
- Park it indoor and cover it with waterproof cloth.
- Keep car away from fire, like stove or heater, or plastic may melt.
- Keep away from flammable things, or may occur fire accident.
- Charge it after use and must be done by adults only. If long time no use, please charge it 1 time per month, in order to maintain battery.
- Clean the vehicle with a dry cloth only. Do not use chemical solvent to wipe plastic parts. Do not wash it with water or play it when raining or snowing. Water will damage motor, electric system or battery.
- Please turn power off after each use.
- Only use charger provided by manufacturer.
- Do not change car's structure or electric line. Check job request some skills or under specialist's guidance.

