

Function Introduction

- Mirror LED ALARM clock
- 5 key operation: ALARM, MODE, LIGHT/SNOOZE, UP, DOWN
- 12/24 hour format
- Month and Date display
- Alarm with snooze
- Indoor Temperature function, Celsius/Fahrenheit selection, test range -10°C ~ +50°C (14°F ~ 122°F)
- Display mode selection: Time display, or time, month/date or indoor temperature circulation display.
- Power way: 3pcs x AAA battery or 5.0V USB charge cable line
- Brightness adjustment function: 2 levels brightness
- Automatic brightness adjustment: 18:00-6:00 Brightness is automatically dimmed, can set the automatic brightness interval
- **Time** memory function 3 AAA battery.

How to Set the Time

- 12Hr/24Hr –Hour-Minute
- Press and hold the MODE button, when the 24Hr flashes, press UP or DOWN button to select 12Hr display or 24Hr display.
- Press MODE button again, when the hour flashes, press UP or DOWN button to select correct HOUR.
- Press MODE button again, when the minute flashes, press UP or DOWN button to select correct MINUTE.
- Press MODE button to quit time setting.




How to Set the Date

- Press MODE button one time to choose MONTH/DATE display, then hold and press the MODE button, when the year (default 2018) flashes, press UP or DOWN button to select correct YEAR.
- Press MODE button again, when month flashes, press UP or DOWN button to select correct MONTH.
- Press MODE button again, when date flashes, press UP or DOWN button to select correct DATE.
- Press MODE button to quit date setting.

How to Set the Alarm

- Press and hold ALARM button, when the hour flashes, press UP or DOWN button to select the alarm hour.
- Press the ALARM button again, when the minute flashes, press UP or DOWN button to select the alarm minute.
- Press the ALARM button again, when the snooze minute flashes, press UP or DOWN button to select the snooze time (the default time is 5 minutes.)
- Press the ALARM button again, when then alarm period flashes, press UP or DOWN button to select the alarm period 1-5 (MON.-FRI.), 1-6 (MON.-SAT.), 1-7 (MON.-SUN.)
- Press the ALARM button to quit the alarm setting.

How to Use the Alarm

- Press the ALARM button, the icon  will appear on the screen, the alarm feature is on.
- Press the ALARM button, the icon  will disappear on the screen, the alarm feature is off.
- When the alarm sound, press the LIGHT/SNOOZE button, will activate the snooze feature, the icon  will always flashes.
- The alarm will auto repeat the next day if the alarm is ON status. will disappear on the screen, the alarm feature is off.

Using the LED Dimmer

- The dimmer will be dark during 18:00-6:00.
- The default dimmer dark time could be set. Under the time display, press three times of the MODE button, when the display show "OFF" or "ON", press UP or DOWN to select ON, then press and hold the MODE button to activate the dark dimmer start time, when the default hour flashes, press the UP or DOWN button to select hour.
- Press the MODE button again, when the minute flashes, press the UP or DOWN to select minute.
- Press the MODE button again, it's the turn of dark dimmer end time, when the hour flashes, press UP or DOWN button to select hour.
- Press the MODE button again, when the minute flashes, press the UP or DOWN to select minute.
- Press the MODE button to quit the setting.
- Press UP button to adjust the dimmer dark or bright.

Display Mode Section

- Press MODE button two times to indoor temperature display, press and hold the MODE button until the BI sound, the time, date and indoor temperature circulation display will be activated. The default the display is time display.

How to Select the Indoor Temperature Celsius/Fahrenheit

- Press MODE button two times to indoor temperature display, press the DOWN button to select Celsius/Fahrenheit.