

WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

**Are you having difficulty
with assembly? Missing parts?**

**PLEASE DON'T RETURN THE ITEM TO
RETAILER**

For help call or email with your order No.

Customer service:

888-214-6610

Open Monday through Friday


9:00AM-5:00PM CST

Email:

customerservice@hulalahome.com

24h

HULALA
H O M E



ITEM NO.CHS18393

NOTE:

This brochure contains IMPORTANT safety info. Please read and keep for future reference.

MAINTAINANCE AND WARNING

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade overtime.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- To obtain the longest lifespan of your outdoor products, avoid exposure to rain or snow, and direct sunshine for long time. Whenever possible cover the product and/or place under patio or awnings.
- Not for commercial use, For residential use only.



Weight Limitation

220LBS

HARDWARE LIST


A*12

M6*20mm




B*2

Front leg




C*1

Left rear leg



D*1

Right rear leg



E*1




Estimated Duration Of Assembly


10-15 MINUTES

PARTS LIST

F*1



G*1



SPARE


H*1
M6*20mm





Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.

ASSEMBLY INSTRUCTIONS


STEP 1:Place the seat upside down on a clean padded surface.





The legs are in the pocket at the bottom of the seat, please open the zipper bag.




STEP 2: Use bolt A, allen key E to attach legs B,C,D to bottom of the seat/back F.



STEP 3: Adjust the levelers to set the whole chair leveled.



STEP 4: Pls insert backrest correctly, then push it down for match up and make sure enough tight. Carefully match the Velcro on back cover then press to secure.



STEP 5: Assembly completed