

BENRINER No.64
SUPER BENRINER No.95


HOW TO CLEAN PARTS AFTER USE

Each part (blade, main body and the Cutting Board) can be removed after use for cleaning. Please do not use a dishwasher as the plastic parts may be damaged by heat.

Note : Cutting Board of "JUMBO BENRINER No.120" cannot be removed.






(1) How to remove Cutting Board (No.64, No.95)



- ① Turn thickness adjusting DIAL to remove from main body.
- ② Keep main body horizontal, and lift up edge of Cutting Board by 90 degrees. Move the Cutting Board to face downwards in the cut-out.

(2) How to attach Cutting Board (No.64, No.95)



Reverse this process to put it back.

- ① Hold the Cutting Board at right angle and locate the two lugs on left and right in Cutting Board Locator.
 - ② Turn the Cutting Board until it is level with main body.
- Please install Thickness Adjustment Dial at the end.

Note: When Thickness Adjustment Dial is installed first, assembly cannot be done.