



PURE GARDEN

PATIO AND GARDEN ESSENTIALS

All Terrain Utility Collapsible Beach Wagon Cart

Use/Features

- Folding Wagon - wagon can support up to 176 lbs, can be used to transport sports equipment, beach accessories, groceries, etc.

Care Instructions

To clean your folding wagon please remove any excess dirt or debris and use a damp cloth to clean. Do not use chemicals to clean this product.



STEP 1 :

remove the folding wagon from the travel sleeve and make sure that the front and rear carrying handles are not secured together.



STEP2:

spread the front and rear frame sections apart and allow the folding wagon to come to a fully extended position.



STEP 3:

pull loop in the center of the wagon bed straight up. put handles together and velcro.

Caution

- Do not use for hot items like food, drinks, pans, grills, hot plates, etc.
- Do not load this wagon with more than 150 lbs.
- Use caution when folding and unfolding the wagon as there is a pinch hazard on the frame.
- Do not tow this product with a bicycle or motorized vehicle.
- This is not intended for use by children. Adult use, only.